



Operating Instructions

Liquicap M FMI51, FMI52 FEI50H HART

Capacitive level measurement





Make sure the document is stored in a safe place such that it is always available when working on or with the device.

To avoid danger to individuals or the facility, read the "Basic safety instructions" section carefully, as well as all other safety instructions in the document that are specific to working procedures.

The manufacturer reserves the right to modify technical data without prior notice. Your Endress+Hauser Sales Center will supply you with current information and updates to these Instructions.

Table of contents

1	Safety instructions	4	7	Maintenance	78
1.1	Designated use	4	8	Accessories	79
1.2	Installation, commissioning and operation	4	8.1	Protective cover	79
1.3	Operational safety	4	8.2	Shortening set for FMI52	79
1.4	Product safety	4	8.3	Commubox FXA195 HART	79
1.5	Notes on safety conventions and icons	5	8.4	HAW56x surge arrester	79
2	Identification	6	8.5	Weld-in adapter	79
2.1	Device designation	6	9	Troubleshooting	80
2.2	Scope of delivery	7	9.1	Error messages at electronic insert	80
2.3	Trademarks	7	9.2	System error messages	80
3	Installation	8	9.3	Possible measuring errors	83
3.1	Quick installation guide	8	9.4	Spare Parts	83
3.2	Incoming acceptance, transport, storage	8	9.5	Return	83
3.3	Planning instructions	9	9.6	Disposal	84
3.4	Measuring condition	10	9.7	Software history	84
3.5	Minimum probe length for nonconductive media ($<1\mu\text{s}/\text{cm}$)	11	10	Technical data	85
3.6	Installation examples	11	10.1	Technical data: probe	85
3.7	With separate housing	16	10.2	Input	85
3.8	Installation instructions	19	10.3	Output	86
3.9	Post-installation check	21	10.4	Performance characteristics	86
4	Wiring	22	10.5	Operating conditions: Environment	88
4.1	Recommendations for connection	22	10.6	Operating conditions: Process	89
4.2	Wiring and connecting	24	10.7	Certificates and approvals	92
4.3	Post-connection check	26	10.8	Documentation	92
5	Operation	27	11	Operating menu	95
5.1	Operating options	27	11.1	"Basic setup" menu Commissioning with display and operating module 95	
5.2	Error messages	39	11.2	"Safety setting" menu	96
5.3	Locking/unlocking configuration	40	11.3	"Linearization" menu	97
5.4	Resetting to factory setting (reset)	40	11.4	"Output" menu	98
5.5	Operation via FieldCare Device Setup	41	11.5	"Device properties" menu	99
5.6	Operation via HART handheld terminal DXR375 .. 42			Index	100
6	Commissioning	43			
6.1	Installation and function check	43			
6.2	Basic setup without the display/operating module 43				
6.3	"Basic setup" menu Commissioning with display and operating module 48				
6.4	"Safety setting" menu	54			
6.5	"Linearization" menu	58			
6.6	"Output" menu	64			
6.7	"Device properties" menu	68			
6.8	Operation	72			
6.9	FieldCare: operating program from Endress+Hauser 72				

1 Safety instructions

1.1 Designated use

Liquicap M FMI51, FMI52 are compact, capacitance level transmitters for the continuous measurement of liquids.

1.2 Installation, commissioning and operation

Liquicap M is designed to meet state-of-the-art safety regulations and complies with the applicable requirements and EC Directives. If used improperly or other than intended, the device can, however, be a source of application-related danger, e.g. product overflow as a result of incorrect installation or configuration. For this reason, installation, electrical connection, commissioning, operation and maintenance of the measuring system must only be carried out by trained technical personnel authorized to perform such work by the owner-operator. The technical personnel must have read and understood these Operating Instructions and must follow the instructions they contain. The device may only be repaired or modified if expressly permitted in the Operating Instructions.

1.3 Operational safety

When performing configuration, testing and maintenance work on the device, alternative supervisory measures must be taken to guarantee the operational safety and process safety.

1.3.1 Ex area

When using the measuring system in Ex-areas, the appropriate national standards and regulations have to be observed. Separate Ex documentation, which constitutes an integral part of this documentation, is supplied with the device. The installation procedures, connection data and safety instructions it contains must be observed.

- Make sure that the technical staff has adequate training.
- The special measuring and safety-related requirements for the measuring points must be observed.

1.4 Product safety

This measuring device is designed in accordance with good engineering practice to meet state-of-the-art safety requirements, has been tested, and left the factory in a condition in which it is safe to operate. It meets general safety standards and legal requirements.

1.4.1 CE mark

The measuring system meets the legal requirements of the applicable EC guidelines. These are listed in the corresponding EC Declaration of Conformity together with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the CE mark.

1.4.2 EAC conformity

The measuring system meets the legal requirements of the applicable EAC guidelines. These are listed in the corresponding EAC Declaration of Conformity together with the standards applied.

Endress+Hauser confirms successful testing of the device by affixing to it the EAC mark.

1.5 Notes on safety conventions and icons

To highlight safety-related or alternative processes, we have designed the following safety instructions where every instruction is indicated by a corresponding pictogram.


Safety instructions	
	Warning! Draws attention to activities or procedures that can result in serious injuries to persons, a safety risk or the destruction of the device if not carried out properly.
	Caution! Draws attention to activities or procedures that can result in injuries to persons or the defective operation of the device if not carried out properly.
	Note! Draws attention to activities or procedures that have an indirect effect on operation, or can trigger an unforeseen device reaction if not carried out properly.
Type of protection	
	Explosion-protected equipment tested for type examination If this sign can be found on the nameplate of the device, the device can be operated in hazardous areas or non-hazardous areas in accordance with the approval
	Ex area This symbol in the drawings in these Operating Instructions indicates Ex-areas. Devices located in Ex-areas, or cables for such devices, must have appropriate explosion protection.
	Safe area (non-hazardous area) This symbol in the drawings in these Operating Instructions indicates non-Ex areas. Devices in non-hazardous areas must also be certified if connecting cables lead into hazardous areas.
Electrical symbols	
	Direct current A terminal to which direct voltage is applied or through which the direct current flows.
	Alternating current A terminal to which alternating voltage (sine wave) is applied or through which the alternating current flows.
	Ground connection A grounded terminal which, from a user's point of view, is grounded via a grounding system.
	Protective earth connection A terminal that has to be grounded before any other connections may be established.
	Equipotential connection A connection that has to be connected to the grounding system of the plant. This can be a potential matching line or a star grounding system, depending on national or company codes of practice.
	Immunity to temperature change of the connecting cables Means that the connecting cables have to withstand a temperature of 85 °C at least.

2 Identification

2.1 Device designation

2.1.1 Nameplate

You can take the following technical data from the nameplate of the device:



Information on the Liquicap M nameplate (example)

L00-FMI5xxxx-18-00-00-en-002

2.1.2 Product structure



Note!

The product structure is used to identify the alphanumeric order number (see nameplate: Order Code).

The following options are available for identification of the measuring device:

- Nameplate specifications
- Order code with breakdown of the device features on the delivery note
- Enter serial numbers from nameplates in W@M Device Viewer (www.endress.com/deviceviewer): All information about the measuring device is displayed.

For an overview of the technical documentation provided, enter the serial number from the nameplates in the W@M Device Viewer (www.endress.com/deviceviewer).

2.2 Scope of delivery



Caution!

Please pay attention to the instructions on unpacking, transporting and storing the measuring devices outlined in the "Incoming acceptance, transport, storage" section on → 8.

The scope of delivery comprises:

- The installed device
- FieldCare Device Setup (operating program)
- Optional accessories (→ 79)

Documentation supplied:

- Operating Instructions
- Approval documentation; if not listed in the Operating Instructions.


2.3 Trademarks

Tri-Clamp®

Registered trademark of Ladish & Co., Inc., Kenosha, USA

3 Installation

3.1 Quick installation guide



- 1.) Screw in the device
2. a) Loosen clamping screw until the housing rotates easily.
2. b) Align the housing.
2. c) Tighten clamping screw (< 1 Nm) until the housing can no longer be rotated.

3.2 Incoming acceptance, transport, storage

3.2.1 Incoming acceptance

Check whether the packaging or content is damaged.

Check that the goods delivered are complete and compare the scope of delivery against the information on your order.

3.2.2 Storage

For storage and transportation, pack the device in such a way as to protect it reliably against impact. The original packaging offers the best protection for this.

The permitted storage temperature is -50°C to $+85^{\circ}\text{C}$.

3.3 Planning instructions


3.3.1 Installation

The Liquicap M FMI51 (rod probe) can be installed from above and from below.
The Liquicap M FMI52 (rope probe) can be installed vertically from above.



Note!

- The probe may not come into contact with the container wall!
- Recommended distance from the container floor: ≥ 10 mm.
- If multiple probes are mounted next to each other, a minimum distance of 500 mm (19.7 in) between the probes must be observed.
- Do not install probes in the area of the filling curtain!
- If using the probe in agitator tanks, make sure the probe is at a sufficient distance from the agitator.
- Rod probes with a ground tube must be used in the event of severe lateral load.



L00-FMI5xxxx-11-06-xx-xx-003

Dimensions mm (in)


3.3.2 Support with marine approval (GL)

Conductive or nonconductive support can be provided for fully insulated rod probes. Partially insulated rod probes may only be supported with insulation at the uninsulated end of the probe.



Note!

- Rod probes with a diameter of 10 mm and 16 mm have to be supported with a length ≥ 1 m (see drawing).



L00-FMI5xxxx-06-05-xx-xx-077

Example for calculating distances:

Probe length $L = 2000$ mm.

$L/4 = 500$ mm

$L/2 = 1000$ mm

Measured from the end of the probe rod = 300 mm.


3.4 Measuring condition

- Measuring range $L1$ possible from the tip of the probe to the process connection.
- Particularly suited for small containers.
- Use a ground tube for nonconductive media.

Note!

When installing in a nozzle, use inactive length ($L3$).

The 0 %, 100 % calibration can be inverted.



L00-FMI5xxxx-15-05-xx-xx-002

Dimensions mm (in)

3.5 Minimum probe length for nonconductive media (<1µs/cm)

$$l_{\min} = \Delta C_{\min} / (C_s * [\epsilon_r - 1])$$

$l_{\min}$ = Minimum probe length

$\Delta C_{\min}$ = 5 pF

C_s = Probe capacitance in air (see also → 85, "Additional capacitance")

ϵ_r = Dielectric constant e.g. oil = 2.0

3.6 Installation examples

3.6.1 Rod probes

Conductive tanks (metal tanks)


If the process connection of the probe is insulated from the metal tank (e.g. using seal material), the ground connection on the probe housing must be connected to the tank using a short line.



Note!

- A fully insulated rod probe may be neither shortened nor extended.
- If the insulation of the probe rod is damaged, this results in an incorrect measurement result.
- These application examples show vertical installation for continuous level measurement.



FMI51: rod probe




L00-FMI5xxxx-11-06-xx-xx-004

FMI51: rod probe with ground tube*Nonconductive tanks (plastic tanks)*


When installing in a plastic tank, a probe with a ground tube must be used.

**FMI51: rod probe with inactive length (e.g. for insulated tanks)**

FMI51: rod probe with ground tube and inactive length (for mounting nozzles)



FMI51: fully insulated probe with clad flange for aggressive media




3.6.2 Rope probes



Note!


These application examples show the installation of rope probes for continuous level measurement.

FMI52: rope probe




L00-FMI5xxxx-11-06-xx-xx-008

FMI52: rope probe with inactive length (e.g. for insulated tanks)



L00-FMI5xxxx-11-06-xx-xx-009

FMI52: rope probe with fully insulated inactive length (for mounting nozzles)

L00-FMI5xxxx-11-06-xx-xx-010


3.6.3 Shortening the rope**Note!**

See Operating Instructions, rope shortening kit KA061F/00.

3.6.4 Tensioning weight with tension


The end of the probe needs to be secured if the probe would otherwise touch the silo wall or another part in the tank. This is what the internal thread in the probe weight is intended for. The bracing can be conductive or insulating to the tank wall.

To avoid too high a tensile load the rope should be loose or gayed with a spring. The maximum tensile load may not exceed 200 Nm.



L00-FMI5xxxx-11-06-xx-xx-012

3.7 With separate housing



Rod length $L1$ max. 4 m

Rope length $L1$ max. 9.7 m (the maximum total length of $L1 + L4$ should not exceed 10 m).



Note!


- The maximum cable length between probe and separate housing is 6 m ($L4$). The required cable length must be indicated in the ordering process of a Liquicap M with separate housing.
- The total length $L = L1 + L4$ should not exceed 10 m (e.g. for rope probes).
- If the cable connection has to be shortened or led through a wall, it must be separated from the process connection.

3.7.1 Extension heights: separate housing

Housing side: wall mounting

Housing side: pipe mounting

Sensor side



Note!

- The cable has a bending radius of $r \geq 100$ mm. This must be observed as a minimum!
- Connecting cable: $\varnothing 10.5$ mm
- Outer jacket: silicone, notch resistance

	Polyester housing (F16)	Stainless steel housing (F15)	Aluminum housing (F17)
B (mm)	76	64	65
H1 (mm)	172	166	177


		H5 (mm)	D (mm)
Probes Ø10 mm rod		66	38
Probes Ø16 mm rod or rope (without fully insulated inactive length)	G¾", G1", NPT¾", NPT1", Clamp 1", Clamp 1½", Universal Ø44, flange <DN 50, ANSI 2", 10K50	66	38
	G1½", NPT1½", Clamp 2", DIN 11851, flanges ≥DN 50, ANSI 2", 10K50	89	50
Probes Ø 22 mm rod or rope (with fully insulated inactive length)		89	38

3.7.2 Wall bracket



Note!


- The wall bracket forms part of the scope of delivery.
- The wall bracket first has to be screwed to the separate housing before you can use it as a drilling template. The distance between the holes is reduced by screwing it to the separate housing.



TT418F20

3.7.3 Wall mounting


- Push the wall bracket onto the tube and screw it together.
- Mark the distance between the holes on the wall and drill the holes.
- Screw the separate housing on the wall.



L00-FMI5xxxx-03-05-xx-xx-010

3.7.4 Pipe mounting

- Push the wall bracket onto the tube and screw it together.
- Screw the separate housing on a pipe of max. 2".



L00-FMI5xxxx-03-05-xx-xx-011

3.7.5 Shortening the connecting cable


Recalibration must be performed before commissioning → 43



Note!

The maximum connection length between the probe and the separate housing is 6 m. When ordering a device with a separate housing, the desired length must be specified.

If the cable connection has to be shortened or led through a wall, it must be separated from the process connection. Please proceed as follows:



L00-FMI5xxxx-03-05-xx-xx-005

- Loosen the pressing screw (1) with an open-end wrench (AF22). If necessary, hold the process connection. Please make sure that neither the connecting cable nor the probe is turning with the pressing screw.
- Pull the insert seal (2) out of the cable gland (5).
- Using an open-end wrench (AF22), disconnect the cable gland (5) from the adapter disk. If necessary, hold it against the adapter disk (7) using an open-end wrench AF34.
- Loosen the adapter disk (7) from the tube (18).
- Remove the snap ring (13) with a pair of snap ring pliers.
- Clutch the nut (M4) of the blade plug with a pair of pliers and pull this out.



Note!


- If you are shortening the connecting cable, we recommend to reuse all strands with ring terminals.
- If the strands are not to be reused, the crimp connections of the new ring terminals fitted must be isolated with a heat shrinking sleeve (risk of short-circuiting).
- All soldered joints must be insulated. Use heat-shrink tubes to do so.

3.8 Installation instructions



Caution!

- Do not damage the probe insulation when installing!
- When screwing in the probe, do not turn at the housing as this could damage the housing mounting.



L00-FMI5xxxx-17-00-00-xx-003

Probe with thread

G ½, G ¾, G 1 or G 1½ (cylindrical):

To be used with the elastomer fiber seal supplied (pay attention to temperature resistance) or another chemically resistant seal.



Note!

The following applies for probes with a parallel thread and supplied seal:

Thread	For pressures up to 25 bar	For pressures up to 100 bar	Maximum torque
G ½	25 Nm	-	80 Nm
G ¾	30 Nm	-	100 Nm
G 1	50 Nm	-	180 Nm
G 1½	-	300 Nm	500 Nm

½ NPT, ¾ NPT, 1 NPT and 1½ NPT (conical):

Wrap the thread by a suitable sealing material (Use conductive sealing material only).

Probe with Tri-Clamp, sanitary connection or flange


- The process seal must meet the specifications of the application (resistant to temperature and medium).
- If the flange is PTFE-clad, this generally suffices as the seal up to the permitted operating pressure.

Probe with PTFE-clad flange

Note!

Use spring washers (1).

It is recommended to retighten the flange bolts periodically, depending on process temperature and pressure. Recommended torque: 60 to 100 Nm.



L00-FMI5xxxx-17-00-00-en-005

3.8.1 Aligning the housing

The housing can be rotated 270° to align the cable entry.

For an even better way of preventing moisture penetration, we recommend you route the connecting cable downwards before the cable gland and secure it with a cable tie. This is particularly recommended when mounting outdoors.


Housing (type F16, F15, F17, F13, T13)

- Unscrew cover
- Loosen Phillips screw at bottom of housing by turning the screw 3 to 4 times
- Turn the housing to the desired position (max. 270°, from one stop to the next)
- Tighten Phillips screw at bottom of housing.



Note!

For housing type T13 with a separate connection compartment, the Phillips screw for aligning the housing is also located in the electronics compartment.



L00-FMI5xxxx-04-00-00-xx-002

1. Loosen clamping screw until the housing rotates easily.
2. Align the housing.
3. Tighten clamping screw ($< 1 \text{ Nm}$) until the housing can no longer be rotated.
4. Additional protection against moisture penetration for electronics compartment.

3.8.2 Sealing the probe housing

No water should enter the device when performing installation, connection and configuration tasks. Always seal the housing cover and cable entries securely.

The O-ring seal on the housing cover is shipped with a coat of special lubricant applied. In this way, the cover can be sealed tight and the aluminum thread does not bite when screwing down.

Never use mineral oil-based grease as this destroys the O-ring.

3.9 Post-installation check

After installing the measuring device, carry out the following checks:

- Is the device damaged (visual inspection)?
- Does the device meet the specifications at the measuring point with regard to process temperature/pressure, ambient temperature, measuring range etc.?
- Has the process connection been tightened with the appropriate tightening torque?
- Are the measuring point number and labeling correct (visual inspection)?
- Is the device adequately protected against precipitation and direct sunshine?

3.9.1 Measuring range with FEI50H (HART)

- Measuring frequency: 500 kHz
- Span: $\Delta C = 25$ to 4000 pF recommended (2 to 4000 pF possible)
- Final capacitance: $C_E = \text{max. } 4000 \text{ pF}$

- Adjustable initial capacitance:
 - $C_A = 0$ to 2000 pF (< 6 m probe length)
 - $C_A = 0$ to 4000 pF (> 6 m probe length)

4 Wiring



Caution!

Before connecting the supply voltage, note the following:

- The supply voltage must match the data specified on the nameplate (1).
- Switch off the supply voltage before connecting the device.
- Connect the potential equalization to the ground terminal on the sensor.



Note!

- When using the probe in hazardous areas, the relevant national standards and the information in the safety instructions (XA) must be observed.
- Use the specified cable gland only.

4.1 Recommendations for connection

4.1.1 Potential equalization



Caution!

In Ex-applications, the screen may only be grounded on the sensor side.

Connect the potential equalization to the outer ground terminal of the housing (T13, F13, F16, F17, F27). In the case of the stainless steel housing F15, the ground terminal (depending on the version) can also be located in the housing.

For further safety instructions, please refer to the separate documentation for applications in hazardous areas.


4.1.2 Electromagnetic compatibility (EMC)

Interference emission to EN 61326, Electrical Equipment Class B. Interference immunity to EN 61326, Annex A (Industrial) and NAMUR Recommendation NE 21 (EMC).

4.1.3 Cable specification

The electronic inserts can be connected using commercially available instrument cables.

When using shielded instrument cables, it is recommended to connect the shielding on both sides to optimize the shielding effect (if potential equalization is present).



* Cable entries

Nickel-plated brass: $\varnothing d = 7$ to 10.5 mm (0.28 to 0.41 in)


Synthetic material: $\varnothing d = 5$ to 10 mm (0.2 to 0.38 in)

Stainless steel: $\varnothing d = 7$ to 12 mm (0.28 to 0.47 in)

4.1.4 Connector

For the version with a connector M12, the housing does not have to be opened for connecting the signal line.

PIN assignment for M12 connector

 L00-FMI5xxxx-04-06-xx-xx-015	PIN	2-wire-electronic insert: FEI50H
	1	+
	2	not used
	3	-
	4	ground

4.1.5 Supply voltage

All of the following voltages are terminal voltages directly at the device:


- 12.0 to 36 VDC (in the non-hazardous area)
- 12.0 to 30 VDC (in Ex ia hazardous areas)
- 14.4 to 30 VDC (in Ex d hazardous areas)

4.2 Wiring and connecting

Connection compartment


Determining the explosion protection:

Housing	Standard	EEx ia	EEx d	Gas-tight process seal
Polyester housing F16	X	X	-	-
Stainless steel housing F15	X	X	-	-
Aluminum housing F17	X	X	-	-
Aluminum housing F13	X	X	X	X
Stainless steel housing F27	X	X	X	X
Aluminum housing T13 (with separate connection compartment)	X	X	X	X




To connect the electronic insert to the power supply, proceed as follows:

- Unscrew the housing cover (1).
- Release the cable gland (2) and insert the cable (3).



L00-FT15xxxx-04-06-xx-xx-003



L00-FT15xxxx-04-06-xx-xx-004


Information on connecting shielded cables is provided in TI241 "EMC test procedures".

4.2.1 Terminal assignment


2-wire, 4 to 20 mA with HART

The twin-core connecting cable is connected to the screw terminals (conductor cross-section 0.5...2.5 mm) in the connection compartment at the electronic insert. If the superimposed communication signal (HART) is used, a screened cable must be used and the screening connected at the sensor and power supply.

Protective circuits against reverse polarity, HF influences and overvoltage peaks are integrated (see TI00241F "EMC test procedures").



4.2.2 Connecting HART with other supply units



Caution!

If the HART communication resistor is not integrated in the supply unit, a 250 Ω communication resistor must be included in the 2-wire line.

4.3 Post-connection check


After wiring the measuring device, carry out the following checks:

- Is the terminal assignment correct (→ 26 ff.)?
- Is the cable gland sealed tight?
- Is the housing cover screwed down until the stop?
- If power supply is present:
 - Is the device operational and is the green LED flashing?


5 Operation

5.1 Operating options

- Via the operating elements at the FEI50H electronic insert
- Via the display and operating module
- Via the HART protocol with Commubox FXA195 and FieldCare operating program
- With the HART handheld terminal DXR375



5.1.1 Display and operating elements at the FEI50H electronic insert



L00-FMI5xxxx-07-05-xx-en-100

Green LED (ⓘ indicates operation):

- Flashes every 5 s:
 - Indicates whether the device is operational.
- Flashes once every s:
 - The device is in the calibration mode

Red LED (⚡ indicates a fault or malfunction):

- Flashes five times a s:
 - Capacitance at probe is too large, short-circuit at the probe or FEI50H is defective
- Flashes once every s:
 - The temperature in the electronic insert is outside the permitted temperature range.

Key (–)

- To execute the functions set via the function switch

Key (+)

- To execute the functions set via the function switch

Function switch

- 1 : Operation
 - Switch position for normal operation
- 2 : Empty calibration
 - Empty calibration is carried out in this operating mode.
- 3 : Full calibration
 - Full calibration is carried out in this operating mode.
- 4 : Measuring modes
 - In this operating mode, chose between operation for media that form buildup (e.g. yoghurt) or for media without buildup (e.g. water).
- 5 : Measuring range
 - In this operating mode, select the measuring range in pF for:
 - => Measuring range probe length < 6 m (corresponds to 2000 pF)
 - => Measuring range probe length > 6 m (corresponds to 4000 pF)
- 6 : Self-test
 - In this operating mode, you can activate the self-test.

- 7 : Reset (factory settings)
 - In this operating mode, you can restore the data of the factory settings.
- 8 : Upload sensor DAT (EEPROM)
 - In this operating mode, you can:
 - => Transfer the calibration values in the electronic insert to the sensor DAT (EEPROM) if replacing the probe
 - => Transfer the calibration values of the sensor DAT (EEPROM) to the electronics if replacing the electronic insert

Display connection


- For onsite display and operation (optional)
 - Display and operating module

4 to 20 mA current pick-off

- E.g. for full/empty calibration with multimeter .
(No need to disconnect circuit!)

5.1.2 Operation via the optional display and operating module

Display and operating elements



L00-FMI5xxxx-19-05-xx-en-012

(a): Name of what is being displayed, e.g. Main menu view; (b): Item code of function displayed; (c): Softkey symbols; (d): Keys

Display symbols

Symbol	Meaning
Operating mode of the device	
	User User parameters can be edited.
	Locked All parameters are locked.
 	Scrollbar This symbol tells you whether you can scroll up or down to get to more functions other than those shown on the display.
Locking state of the currently displayed parameter	
	Display parameter The parameter cannot be edited in the current operating mode of the device.
	Write parameter The parameter can be edited.

Keys (softkey operation)

The keys work as softkeys. This means that their function and meaning depends on the current position in the operating menu. The key functions are indicated by softkey symbols in the bottom line of the display.

Symbol	Meaning
	Down Moves the bar downwards in a picklist.
	Up Moves the bar upwards in a picklist.
	Enter - Enter the selected submenu or selected function. - Confirm the edited function value.
	Previous function Go to the previous function within the function group.
	Next function Go to the next function within the function group.
	Confirm selection From the picklist, select the option the bar is currently on.
	Increase value Increases the selected position of an alphanumeric function.
	Decrease value Decreases the selected position of an alphanumeric function.
	Error list Opens the list of the errors currently present. The symbol is inverted and flashes if a warning is present. The symbol appears constantly if an alarm is present.

General key combinations


The following key combinations apply regardless of the menu item in question:

Key combinations	Meaning
	Escape - When editing a function: exits the editing mode for the current function. - When navigating: returns to the next-highest menu level.
	Increase contrast Increases the contrast of the display module.
	Decrease contrast Decreases the contrast of the display module.
	Locking Locks the device against parameter changes. Locking can only be reversed by entering a release code.

5.1.3 The operating menu

Function codes

The functions of Liquicap M are arranged in an operating menu. A 5-digit item code is shown on the display for every function to aid orientation within the menu.




A: Function group; **B:** Channel; **C:** Number of the function within the group

- The first position (A) refers to the function group¹⁾:
 - **C: Basic setup**
 - **S: Safety setting**
 - **L: Linearization**
 - **O: Output**
 - **D: Device properties**
- The second position (B) is without function.
- The last three positions (C) refer to the individual functions within the function group.

1) The function groups available depend on the device version, the installation environment and the operating mode selected.

Navigating in the menu - Basic setup example



L00-FMI5xxxx-05-06-xx-en-002


Launching menus



Note!

If you are within a submenu and do not press a key for 15 minutes, the display automatically switches to the main screen (measured value).

Navigation always starts with the main screen (measured value display). From here, you can go to the following menus with the aid of the keys:



L00-FMI5xxxx-19-05-xc-en-011

■ Measured value

Displays the measured value in %, mA or pF.

■ Main menu

The main menu contains all the parameters of Liquicap M. It is split into submenus. Some of the submenus themselves have additional submenus.

An overview of the submenus and the functions they contain is provided in the "Commissioning" section.

■ Actual errors

If the automatic monitoring function of Liquicap M detects an error, the related softkey symbol appears over the center key.


If the softkey symbol is flashing, only "Warning"-type errors are present²⁾.

If the symbol is displayed continuously, at least one "Alarm"-type error is present²⁾.

Once you press the key, a list appears with all the errors currently pending.

2) See Section 9.2, "System error messages" for information on the difference between a "Warning" and an "Alarm".

Selecting a submenu



L00-FMI5xxxx-19-05-xx-en-001

1. Press W or V until the desired submenu is selected.
2. Press ↵ to enter the selected submenu.
3. If the submenu contains additional submenus, continue in the same manner until you reach the function level. The softkey symbols U and T then appear.




Note!

You can return to the next-highest menu level any time by pressing .

Selecting a function and subfunction

Once you have reached the function level, you can navigate through the functions with U and T. The current values of all the related subfunctions are displayed. Proceed as follows to change a value:



1. Press U or T until you reach the desired function.
2. Press ↵ to enter the selected function.
3. Use W and V to select the desired subfunction. (This step is not necessary if the function only has one subfunction.)
4. Press ↵ to enter the subfunction. The editing process that follows depends on the type of subfunction selected (picklist, numeric function or alphanumeric function). Details are explained in the following sections.


L00-FMI5xxxx-19-05-xx-en-002



Note!

You can leave the function at any time and return to the next-highest menu level by pressing the left arrow button (←).

Editing functions with the picklist



1. Press W or V until the bar is on the desired option (here: "m").
2. Press ↵ to select this option. The new value is now transferred to the device. If required, you can edit another subfunction in the same way.


L00-FMI5xxxx-19-05-xx-en-003



Note!

You can leave the function at any time and return to the next-highest menu level by pressing .

Editing numeric and alphanumeric functions




If you select a numeric function ("Empty calibration", "Full calibration" etc.) or an alphanumeric function ("Device marking" etc.), the editor for numbers/alphanumeric characters opens.

Enter the desired value as follows:

1. The marker is on the first position. Press S or O until this position shows the desired value.
2. Press ↵ to enter the value and go to the next position.
3. Follow the same procedure for the positions that follow.
4. Once all the necessary positions have been entered, press S or O until ↵ appears at the marker.
5. Press ↵ to transfer the entire value to the device.


Special functions when making entries

In the editor for numbers and alphanumeric characters, the S and O keys not only call up numbers and letters but also call up the following symbols for special editing tasks which make inputting information easier and make it possible to make corrections quickly.




L00-FMI5xxxx-19-05-xx-en-005

Enter: The number to the left of the marker is transferred to the device.




L00-FMI5xxxx-19-05-xx-en-006

Escape: You exit the editor. The old function value remains.




L00-FMI5xxxx-19-05-xx-en-007

Next position: The marker jumps to the next position.



L00-FMI5xxxx-19-05-xx-en-008


Previous position: The marker jumps back to the previous position.



L00-FMI5xxxx-19-05-xx-en-009

Delete: The current position and all positions to the right of this position are deleted.

Return to the measured value display



L00-FMI5xxxx-19-05-xx-en-010

Pressing the left and center key simultaneously has the following effect:

- Takes you from the editing mode to the display mode of the functions
- Takes you from the display mode of the functions to the submenu
- Takes you from the submenu to the main menu
- Takes you from the main menu to the measured value display.

5.2 Error messages

If the automatic monitoring function of Liquicap M detects an error, the related softkey symbol $\downarrow$ appears over the center key.

If the softkey symbol $\downarrow$ is flashing, only "Warning"-type errors are present³⁾.

If the symbol is displayed continuously, at least one "Alarm"-type error is present³⁾.

Once you press the key, a list appears with all the errors currently pending.

3) See Section 9.2, "System error messages" for information on the difference between a "Warning" and an "Alarm".

5.3 Locking/unlocking configuration

5.3.1 Key locking

Press all three keys simultaneously. The device is then locked against entries.

5.3.2 Key unlocking

Press all three keys simultaneously. The device is then unlocked.

5.3.3 Software locking

Locking

Go to the "Safety settings" function.

In the menu, the current locking status of the device is displayed in the "Status" subfunction under "Safety settings" (SAX01). The following values can appear:

- **Unlocked**

All parameters can be modified.

- **Locked**

The device has been locked by means of the operating menu. It can only be enabled again by entering "100" in the "Safety settings" function.

If an attempt is made to change a parameter, the device goes to the "Safety settings" function. "Key locking" is displayed in the "Status" subfunction. Press all the keys simultaneously. The device then goes back to the original function and all the parameters can be changed again.

- **Key locked**

The device has been locked by means of the operating keys. It can only be enabled again by pressing all three keys simultaneously.



Note!

A key symbol is shown on the display when locked.

5.4 Resetting to factory setting (reset)



Caution!

The reset can affect the measurement as the current values are overwritten by those of the factory calibration 0 % (4 mA) and 100 % (20 mA).

Using the reset

A reset is always recommended if a device with an unknown history is to be used.

Effects of a reset

- All parameters are reset to the factory setting.
- The linearization is reset to "linear". However, any linearization table available is retained and can be activated again where necessary.



Note!

The factory setting of the parameters is marked in bold in the menu overview (see the "Basic setup" menu ff.).

Performing a reset

To carry out a reset, enter the value "333" in the "Device properties/Diagnosis/Password reset/Reset" function.

5.5 Operation via FieldCare Device Setup

5.5.1 FieldCare Device Setup - operating program

FieldCare is a graphic operating program for Endress+Hauser measuring devices based on the time-of-flight principle. It is used to support commissioning, data back-up, signal analysis and documentation of the devices. The following operating systems are supported: Windows 2000, Windows XP, Windows Vista and Windows 7.

FieldCare supports the following functions:


- Configuration of transmitters in online operation
- Tank linearization
- Loading and saving device data (upload/download)
- Documentation of the measuring point



Note!

Further information on FieldCare is provided on the CD-ROM which is supplied with the device.

Menu-guided commissioning




Connection options:

- HART with Commubox 195

5.6 Operation via HART handheld terminal DXR375

The handheld terminal DXR375 (Field Communicator) can be used to set all device functions via menu operation.



Menu operation with the DXR375 handheld terminal



Note!

- Further information on the HART handheld terminal can be found in the associated Operating Instructions which can be found in the carrying case for the device.

6 Commissioning



Note!

The device is operated via the electronic insert, the display or with FieldCare. If a display is attached to the electronic insert, the function keys (- key/ + key) and the Mode switch at the electronic insert are deactivated. All other settings can be made using the function keys on the display or with FieldCare.

6.1 Installation and function check

Make sure that the post-installation check and final check have been completed before you start your measuring point:

- See "Post-installation check" checklist → 21
- See "Post-connection check" checklist → 26

6.2 Basic setup without the display/operating module

This section describes how to commission the device with the function switch and the operating keys (-/+) on the FEI50H electronic insert.




Note!

- On leaving the factory, Liquicap M devices are calibrated for media with a conductivity of $\geq 100 \mu\text{S}/\text{cm}$ (e.g. for all water-based liquids, acids, alkalis ...). A recalibration is only necessary if the 0 %-value or the 100 %-value should be adjusted to suit customer-specific requirements, the distance to the tank wall is $< 250 \text{ mm}$ or if the liquid is not conductive.
- Only the "Wet" type of calibration can be carried out without the display and operating module.

During wet calibration ("Wet" operating mode), the 0 %-value and/or the 100 %-value is adjusted to customer-specific requirements. This calibration can be carried out if the tank is empty, full or partially full. During full calibration, the probe must be covered by liquid in the installed state.

An empty and full calibration must be performed.



L00-FMI5xxxx-07-05-xx-en-100

6.2.1 Function switch - position 1 Operation

In normal operation, the function switch must be set to position 1.

6.2.2 Function switch - position 4 Measuring modes



Note!

Before carrying out empty and full calibration, the medium properties must be configured. If the medium is conductive and tends to form buildup, the "Buildup" operating mode must be selected.

In this operating mode, the buildup on the probe rod is compensated.

The "No buildup" operating mode is set at the factory.

"Medium property" subfunction

The **"No buildup"** operating mode should be set for media that do not tend to form buildup on the probe rod (e.g. water, beverages etc.). As of a conductivity of 100 $\mu\text{S}/\text{cm}$ (i.e. all water-based liquids, acids, alkalis ...), the measured value is independent of the conductivity of the liquid (independent of concentration fluctuations).

In the **"Buildup"** operating mode, the buildup compensation function integrated in the software is activated. In this operating mode, the measured value is independent of the conductivity of the liquid as of a conductivity of 1000 $\mu\text{S}/\text{cm}$ (independent of concentration fluctuations).

This compensates measuring errors caused by conductive media sticking to the probe rod (e.g. yoghurt). This corresponds to buildup compensation.

Proceed as follows to choose between media forming buildup (e.g. yoghurt) and media not forming buildup (e.g. water):

- Turn the function switch to position 4
- "Buildup" operating mode
 - => Press the + key for media that tend to form buildup.
 - => The green LED confirms your entry by flashing three times.
- "No buildup" operating mode
 - => Press the – key for media that do not form buildup.
 - => The green LED confirms your entry by flashing three times.

6.2.3 Function switch - position 2 Carry out empty calibration (for empty tanks)

If the tank is empty (0 %), the empty calibration sets the signal current to the lower value of 4 mA. When empty calibration is completed, the current value of 4 mA is displayed at the ammeter.

Proceed as follows to perform empty calibration:

- Turn the function switch to position 2
- Press the – and + keys together for approx. 2 s until the green LED flashes*
 - => Release the two keys again.
 - => The flashing stops after approx. 5 s.
 - => Empty calibration is saved.

* SW version 1.00.00 flashes red.

6.2.4 Function switch - position 2 Carry out empty calibration (for almost empty tanks)

If possible, the exact level of the tank should be known and should not be too large (< 30 %).

Too high a level reduces the accuracy of the zero point (corresponds to the empty tank). An ammeter must be connected to the current pick-off at the electronic insert.

Let us presume that the level was determined for 15 %. Now the current value that corresponds to the level of 15 % must be determined. The lower current value can be adjusted with the +/- keys. The + key increases the value, the - key reduces the value. The following must also be considered:

1. The lower current value (= empty tank, 0 %) is 4 mA.
2. The upper current value (= full tank, 100 %) is 20 mA.
3. This results in a measuring range of 16 mA for a change from 0 % to 100 %, i.e. 0.16 mA increase in the current for every 1 % increase in the level.
4. For a 15 % level, this is 15 % x 0.16 mA/% which equals 2.4 mA. This must be added to the 4 mA to obtain the current value to be set: 2.4 mA + 4 mA = 6.4 mA.

Proceed as follows to perform empty calibration on a partially filled tank:

- Turn the function switch to position 2
- The current value can be adjusted with the +/- keys. For this purpose, press the + or - key for at least 2 seconds. You can set the desired current value (> 4 mA) using the multimeter connected.
- The empty calibration is saved when you release the key.

6.2.5 Function switch - position 3 Carry out full calibration (for full tanks)

If the tank is full (100 %), the full calibration sets the signal current to the upper value of 20 mA. When empty calibration is completed, the current value of 20 mA is displayed at the ammeter.

Proceed as follows to perform full calibration:

- Turn the function switch to position 3
- Press the - and + keys together for approx. 2 s until the green LED flashes*
=> Release the two keys again.
=> The flashing stops after approx. 10 s.
=> Full calibration is saved.

* SW version 1.00.00 flashes red.

6.2.6 Function switch - position 3 Carry out full calibration (for almost full tanks)

If possible, the exact level of the tank should be known and should be as large as possible (> 70 %).

Too low a level reduces the accuracy of the upper point (corresponds to the full tank). An ammeter must be connected to the current pick-off at the electronic insert.

Let us presume that the level was determined for 90 %. Now the current value that corresponds to the level of 90 % must be determined. The upper current value can be adjusted with the +/- keys. The + key increases the value, the - key reduces the value.

The following must also be considered:

1. The lower current value (= empty tank, 0 %) is 4 mA.
2. The upper current value (= full tank, 100 %) is 20 mA.
3. This results in a measuring range of 16 mA for a change from 0 % to 100 %, i.e. 0.16 mA increase in the current for every 1 % increase in the level.

4. For a 90 % level, this is $90 \% \times 0.16 \text{ mA}/\%$ which equals 14.4 mA. This must be added to the 4 mA to obtain the current value to be set: $14.4 \text{ mA} + 4 \text{ mA} = 18.4 \text{ mA}$. (You can also take the upper current value and then subtract $10 \% \times 0.16 \text{ mA}/\% = 1.6 \text{ mA}$ from 20 mA.)

Proceed as follows to perform full calibration on a partially filled tank:

- Turn the function switch to position 3
- The current value can be adjusted with the +/- keys. For this purpose, press the + or - key for at least 2 seconds. You can set the desired current value (< 20 mA) using the multimeter connected.
- The full calibration is saved when you release the key.

6.2.7 Function switch - position 5 Measuring range

At the factory, the measuring range is always calibrated to the probe length ordered. If the electronic insert is used in another probe, the measuring range must be configured in accordance with the probe length.

Proceed as follows to configure the measuring range 2000 pF (probe length < 6 m) or 4000 pF (probe length > 6 m):

- Turn the function switch to position 5
- Press the - key to set 2000 pF
=> The green LED confirms your entry by flashing three times.
- Press the + key to set 4000 pF
=> The green LED confirms your entry by flashing three times.

6.2.8 Function switch - position 6 Proof test (self-test)



Note!

- From version FW: V 01.03.00
- Before and after the automatic proof test, it is essential to check whether the level value displayed corresponds to the actual level value.

When the self-test is activated, the current output is set to 4 mA and follows a ramp function up to 22 mA. This test is completed after approx. 40 s.

Proceed as follows to activate the device self-test:

- Turn the function switch to position 6
- Press the - and + keys together to start the function test
=> The green LED flashes quickly until the error current is reached. The red LED flashes until the test is completed.



Note!

After the self-test, the device automatically returns to the operating mode.

6.2.9 Function switch - position 7 Reset - restore factory settings



Caution!

The reset can affect the measurement as the current values are overwritten by those of the factory calibration (0 % (4 mA) and 100 % (20 mA)).

Proceed as follows to restore the factory settings:

- Disconnect the electronic insert from the power supply
- Turn the function switch to **position 7**

- Press and hold the – and + keys together while the device is being reconnected to the power supply
=> red LED flashes slowly and then starts to flash quickly
- The device reset is complete when the red LED goes out
- Release the – and + keys again

6.2.10 Function switch - position 8 Download/Upload sensor DAT (EEPROM)

Calibration values can be transmitted with this function. A distinction is made between two types:

- The sensor has been replaced and the electronic insert should continue to be used.
- The electronic insert has been replaced but the sensor should continue to be used.

For instances of this nature, the calibration values already set can be transferred from the sensor to the electronic insert or from the electronic insert to the sensor.

Proceed as follows to transfer the calibration values from the electronic insert to the sensor:

Download

- Turn the function switch to position 8
- Press the – key to start downloading from the electronic insert to the sensor
=> The green LED flashes for approx. 2 s, thereby confirming your entry.
=> The device now restarts.

Proceed as follows to transfer the calibration values from the sensor to the electronic insert:

Upload

- Turn the function switch to position 8
- Press the + key to start uploading from the sensor to the electronic insert
=> The green LED flashes for approx. 2 s, thereby confirming your entry.
=> The device now restarts.

6.3 "Basic setup" menu

Commissioning with display and operating module



Note!

This section describes how to commission the Liquicap M by means of the display and operating module. The procedure for commissioning by means of FieldCare or the DXR375 handheld terminal is the same. More detailed information can be found in the Operating Instructions for FieldCare (BA 224F/00) or for DXR375 (is supplied together with the handheld terminal).

6.3.1 Initial commissioning

On first power-up, you are requested to select the language for the display texts. After this selection the measured value is displayed.



Note!

If a reset is performed at the device and if the power supply is switched off and on again, the language of the display texts has to be selected again.

Menu structures: Main menu

The main menu is activated by means of the right Enter key ↵.

The following menu headings appear. These are explained in more detail over the following pages:

- "Basic setup"
- "Safety setting" (→ 54)
- "Linearization" (→ 58)
- "Output" (→ 64)
- "Device properties" (→ 68)



Note!


- Liquicap M devices are calibrated on leaving the factory for media with a conductivity of $\geq 100 \mu\text{S}/\text{cm}$ (e.g. for all water-based liquids, acids, alkalis ...). A recalibration is only necessary if the 0 %-value or the 100 %-value should be adjusted to suit customer-specific requirements, the distance to the tank wall is $< 250 \text{ mm}$ or if the liquid is not conductive.
- A distinction is generally made between two types of calibration:

Wet calibration:

During wet calibration ("Wet" operating mode), the probe must be covered by liquid in the installed state. This calibration can be carried out if the tank is empty, full or partially full. Empty and full calibration must be performed.

Dry calibration

During dry calibration, empty and full calibration can be carried out without the probe being in contact with the liquid. The calibration values can be entered directly in units of length (e.g. m, mm, ...) for example.




L00-FMI5xxxx-15-05-xx-en-000

You can make the following settings in the "Basic setup" menu:

Menu	Function	Subfunction	Function value
	 	 	
Basic setup	Basic setup	Medium property	no buildup ¹⁾ buildup
		Cal. type	Dry Wet
	Medium property ²⁾	Medium property	Conductive Nonconductive ³⁾ interface unknown
		DC value ⁴⁾	Value
		Unit level ⁵⁾	% (percentage) m mm ft inch
	Empty calibr.	Value empty	0 %
		Measure capacity	xxxx pF
		Confirm cal.:	Yes
	Full calibr.	Value full	100 %
		Measure capacity	xxxx pF
		Confirm cal.:	Yes
	Output damping	Output damping	1 s

- 1) Factory settings are marked in "bold".
- 2) This function is only displayed if the function value "Dry" was selected under the subfunction "Cal. type".
- 3) This function value can only be selected for probes with a ground tube.
- 4) This subfunction is only displayed if the function value "Nonconductive" was selected under the subfunction "Medium property".
- 5) This subfunction is only displayed if the function value "Nonconductive" or "Conductive" was selected under the subfunction "Medium property".

6.3.2 "Basic setup" function



Basic setup CLX00
Medium : no buildup
Cal. type: Wet

"Medium property" subfunction

The **"No buildup"** operating mode should be set for media that do not tend to form buildup on the probe rod (e.g. water, beverages etc.). As of a conductivity of 100 $\mu\text{S}/\text{cm}$ (i.e. all water-based liquids, acids, alkalis ...), the measured value is independent of the conductivity of the liquid (independent of concentration fluctuations).

In the **"Buildup"** operating mode, the buildup compensation function integrated in the software is activated. In this operating mode, the measured value is independent of the conductivity of the liquid as of a conductivity of 1000 $\mu\text{S}/\text{cm}$ (independent of concentration fluctuations).

This compensates measuring errors caused by conductive media sticking to the probe rod (e.g. yoghurt). This corresponds to buildup compensation.

"Cal. type" subfunction

In the **"Dry"** "Cal. type" empty and full calibration can be carried out without the probe being in contact with the liquid. The calibration values can be entered directly in units of length (e.g. m, mm, ...) for example.

In the **"Wet"** "Cal. Type", the probe must be covered by liquid in the installed state for full calibration. This calibration can also be carried out if the tank is partially full. Both the empty calibration and full calibration must be performed.

6.3.3 "Medium property" function



Note!

This function is only displayed if the function value "Dry" was selected under the subfunction "Cal. type".

"Medium property" subfunction

The properties of the medium are entered here.

- **"Nonconductive"**: the conductivity of the medium is $\leq 1 \mu\text{S}/\text{cm}$ (only with ground tube)
- **"Conductive"**: the conductivity of the medium is $\geq 100 \mu\text{S}/\text{cm}$
- **"Interface"**: the properties of the two media can be entered in the operating program of ToF Tool. The associated calibration values are then calculated.
- **"Unknown"**: the medium properties are not known. The capacitance values of the "Empty calibr." and "Full calibr." functions can be entered directly.

"DC value" subfunction



Note!

This subfunction is only displayed if the function value "Nonconductive" was selected under the subfunction "Medium property".

The dielectric constant for the liquid to be measured is entered here (e.g. 3.4)

"Unit level" subfunction

Note!

This subfunction is only displayed if the function value "Conductive" or "Nonconductive" was selected under "Medium property".

The desired level unit for Basic setup is entered here.

6.3.4 "Empty calibr." function ("Wet" operating mode)

Note!

The calibration data can be calculated with **CapCalc.xls** → 74.

With "Empty calibration", the 0 % value or the 4 mA value is assigned to the level value.



Note!

The procedure applies to the "Wet" type of calibration. Information on "Dry" calibration is provided further below.

"Value empty" subfunction

The current level value is entered here,

e.g. 5 % partial filling => "Value empty" 5 % or

e.g. 0 % partial filling => "Value empty" 0 %



Note!

To keep the calibration error to a minimum, the level should be between 0 % and 30 %.

"Measure capacity" subfunction

The capacitance value currently measured is displayed here.

"Confirm cal." subfunction

In this function, empty calibration is confirmed and the "Measure capacity" currently measured is assigned to the percentage level value entered above ("Value empty").

6.3.5 "Full calibr." function ("Wet" operating mode)

With "Full calibration", the 100 % value or the 20 mA value is assigned to the level value.



Note!

The procedure applies to the "Wet" type of calibration. Information on "Dry" calibration is provided further below.

"Value full" subfunction

The current level value is entered here,

e.g. 90 % partial filling => "Value full" 90 % or

e.g. 100 % filling => "Value full" 100 %



Note!

To keep the calibration error to a minimum, the level should be between 70 % and 100 %.

"Measure capacity" subfunction

The capacitance value currently measured is displayed here.

"Confirm cal." subfunction

Full calibration must be confirmed with this function.

6.3.6 "Empty calibr." function ("Dry" operating mode)

The "Empty" value can be entered directly in units of length if the medium property has been set to conductive or nonconductive.

"Value empty" subfunction, medium property (conductive, nonconductive)

In this function, specify the distance E, i.e. the distance from the active probe rod to the desired zero point.

Value E:

Empty calibration $\leq$ active probe length

$E \leq L1 - (\text{thread length } H4 + \text{plug})$

Thread length:

H4 for G1½ = 25 mm


H4 for G < 1½ = 19 mm

Plug:

10 mm rod = 10 mm

16 mm rod = 15 mm

22 mm rod = 15 mm



"Cap. empty" subfunction

The calculated capacitance value is displayed here. This field cannot be edited.

"Confirm cal." subfunction

Empty calibration is confirmed with this subfunction.

6.3.7 "Full calibration" function ("Dry" operating mode) for conductive and nonconductive media


The "Full" value can be entered directly in units of length.

"Value full" subfunction, medium property (conductive, nonconductive)

In this function, specify the span F, i.e. the distance from the zero point to the desired 100% point.

"Value full"

$F \leq E$ "Value empty" ($\rightarrow$ 52)



"Cap. full" subfunction

The calculated capacitance value is displayed here. This field cannot be edited.

"Confirm cal." subfunction

Full calibration is confirmed with this subfunction.

6.3.8 "Empty calibration" function ("Dry" operating mode for "Interface" or "Unknown" medium properties)**"Value empty" subfunction**

This field displays 0 % and cannot be edited.

"Cap. empty" subfunction

Enter the capacitance value calculated with CapCalc.xls, for example, (capacitance calculation program in FieldCare) here.

"Confirm cal." subfunction

Empty calibration must be confirmed with this subfunction.

6.3.9 "Full calibration" function ("Dry" operating mode for "Interface" or "Unknown" medium properties)**"Value full" subfunction**

This field displays 100 % and cannot be edited.

"Cap. full" subfunction

The capacitance value calculated with CapCalc.xls, for example, (capacitance calculation program in FieldCare) is entered here.


"Confirm cal." subfunction

Full calibration must be confirmed with this subfunction.

6.3.10 "Output damping" function

With this function, you can set the reaction time of your measuring device to changes in the level. If surfaces are turbulent, a higher output damping (e.g. 2 s) should be selected.

6.4 "Safety setting" menu



Safety settings SAX01
Code: 100
Status: unlocked

You can make the following settings in the "Safety settings" menu.

Menu	Function	Subfunction	Function value
	 	 	
Safety settings	Safety settings	Code	100¹⁾
		Status	Unlocked Locked
	Safety settings	Operating mode	Standard SIL/WHG
		Output damping	1 s
		Output 1	MAX
		Parameter okay	no Yes
	Safety settings	Cap. empty	x,xx pF
		Value empty	x,xxx %
		Cap. full	2000.00 pF
		Value full	100.000 %
		Parameter okay	no Yes
	Operating mode	Operating mode	Standard SIL/WHG
		SIL op. mode ²⁾	Unlocked Locked
		Status	Unlocked Locked
	Output on alarm	Output	Max Hold User-spec.
		Output value ³⁾	xx.xx mA
	Proof test	Proof test	Off On

- 1) Factory settings are marked in "bold".
- 2) This subfunction is only displayed if the "SIL/WHG" option was selected under the "Operating mode" subfunction.
- 3) This subfunction is only displayed if the "User-specific" option was selected under the "Output" subfunction.

6.4.1 "Safety settings" function

"Code" subfunction

With this subfunction, you can lock the device against unpermitted or unintentional changes.

- Enter a number ≠ 100 to lock the device. Parameters can then no longer be modified.
- Enter "100" to unlock the device. Parameters can then be modified again.

"Status" subfunction

This subfunction displays the current locking status of the device. The following values can appear:

- **"Unlocked"**

All writeable parameters can be modified.

- **"Locked"**

The device has been locked via the operating menu ("Code" subfunction). It can only be unlocked by entering "100" in the "Code" subfunction.

6.4.2 "Safety settings" function

"Operating mode" subfunction

This subfunction displays the set operating mode and cannot be edited.

Possible operating modes:

- Standard
- SIL/WHG

"Output damping" subfunction

This subfunction displays the output damping set. Output damping is the time at which the measuring system reacts to changes in level and is between 0 and 60 seconds.

"Output 1" subfunction

This subfunction displays the set value the output assumes in an alarm condition. Possible values are:

- MAX (22 mA)
- Hold (the last value is held)
- User-spec.

"Parameter okay" subfunction

With this subfunction, you confirm that the parameter values displayed under the "Safety settings II" function are correct.



Note!

The "Parameter okay" subfunction has to be confirmed with "Yes" so the device can be locked for the SIL/WHG operating mode. In addition, the SIL/WHG function value has to be selected for the "Operating mode" subfunction and "Locked" must be set for the "Status" subfunction. The device can be unlocked using the special release code. The release code is "7452".

6.4.3 "Safety settings" function

"Cap. empty" subfunction

This subfunction displays the measured capacitance during empty calibration in pF.

"Value empty" subfunction

This subfunction displays the empty calibration value in %.

"Cap. full" subfunction

This subfunction displays the measured capacitance during full calibration in pF.

"Value full" subfunction

This subfunction displays the full calibration value in %.

"Parameter okay" subfunction

With this subfunction, you confirm that the parameter values displayed under the "Safety settings II" function are correct.



Note!

The "Parameter okay" subfunction has to be confirmed with "Yes" so the device can be locked for the SIL/WHG operating mode. In addition, the SIL/WHG function value has to be selected for the "Operating mode" subfunction and "Locked" must be set for the "Status" subfunction. The device can be unlocked using the special release code. The release code is "7452".

6.4.4 "Operating mode" function

"Operating mode" subfunction

With this subfunction, you can switch from the Standard operating mode to the SIL/WHG operating mode:

- "Standard"
- "SIL/WHG"

The following parameters are set to defined values in the "SIL/WHG" operating mode:

- Output damping: Output damping is fixed at "1 s"
- Output on alarm: The "Output on alarm" function is fixed at "22 mA".

In the "SIL/WHG" operating mode, cyclic self-monitoring of the device takes place (e.g. memory test, processor test, current output ...).

"SIL operating mode" subfunction

You can lock or unlock the device in this subfunction. No parameters can be changed in the locked state.

"Status" subfunction

This subfunction displays the current locking status of the device. The following values can appear:

- "Unlocked"
All writeable parameters can be modified.
- "Locked"
The device has been locked via the operating menu ("Code" subfunction). It can only be unlocked by entering "100" in the "Code" subfunction.

6.4.5 "Safety settings" function

"Operating mode" subfunction

The "Standard" or "SIL/WHG" operating mode entered is displayed here.

"Output damping" subfunction

The output damping entered is displayed here.

"Value empty" subfunction

The capacitance of the empty calibration is displayed here.

"Value full" subfunction

The capacitance of the full calibration is displayed here.

"Parameter okay" subfunction

With this subfunction, you confirm that the parameter values displayed under the "Safety settings II" function are correct.



Note!

The "Parameter okay" subfunction has to be confirmed with "Yes" so the device can be locked for the SIL/WHG operating mode. In addition, the SIL/WHG function value has to be selected for the "Operating mode" subfunction and "Locked" must be set for the "Status" subfunction. The device can be unlocked using the special release code. The release code is "7452".


6.4.6 "Output on alarm" function

"Output" subfunction

This function determines the value the output in question assumes when an alarm condition occurs.

Options:

- **"Max"**
22 mA
- **"Hold"**
The last value is retained
- **"User-spec."**
As defined in the "Output value" subfunction



A: Max.; B: User-specific (between 3.8 and 22 mA); C: Hold

L00-FMI5xxxx-19-05-xx-xx-006

"Output value" subfunction (only for "Output", "User-specific")

In this function, specify the user-specific value the current output should assume in an alarm condition.

- Value range: 3.8 to 22 mA

6.4.7 "Proof test" function (self-test)



Note!


- From version FW: V 01.03.00
- Before and after the automatic proof test, it is essential to check whether the level value displayed corresponds to the actual level value.
- After the self-test, the device automatically returns to the operating mode.

"Proof test" subfunction

With this subfunction, you activate the device self-test. All electronic components relevant to the function are tested. In a ramp of approx. 40 s, the current output goes through the range of 4 to 22 mA.

6.5 "Linearization" menu

"Linearization" is used for converting the level to any unit. You can determine the volume or the mass in a tank of any shape. Liquicap M makes various linearization modes available for situations that occur frequently. Furthermore, a linearization table can be entered for tanks and containers of any shape.



Linearization L1008
Type: None
Mode: Level
Simulation: Sim. off

Note!
The number and type of subfunctions depend on the type of linearization selected.
Only the "Type" and "Mode" subfunctions are always available.

You can make the following settings in the "Linearization" menu:

Menu	Function	Subfunction	Function value	Additional function values
Linearization	Linearization	Type	None Linear ¹⁾ Horizontal cyl ²⁾ Sphere ²⁾ Pyramid bottom ³⁾ Conical bottom ³⁾ Angled bottom ³⁾ Table	
		Mode	level Ullage	
		Simulation	Sim. off Sim. level Sim. volume	
		Sim. level value ⁴⁾ or Sim. vol. value ⁴⁾	xx.x % xx.x %	
		Linearization	Customer unit	% (percentage), l, hl, m3, dm3, cm3, ft3, usgal, igoal, kg, t, lb, ton, m3, ft3, mm, inch, user-spec.
			Customized text ⁵⁾	...
			Diameter ⁶⁾	xxxx m
			Intermed. height ⁷⁾	xx m
		Edit ⁸⁾	Read	Table No.: 1 Input level: x m Input volume: %
			Manual	Table No.: 1 Input level: x m Input volume: %
			Semi-automat.	Table No.: 1 Input level: x m Input volume: %
			Delete	
		Status table ⁷⁾	Enabled Disabled	
		Max. scale ⁹⁾	100 %	

- 1) Factory settings are marked in "bold".
- 2) If you enter a value for this function, you must also enter a value for the "Diameter" subfunction in another step.
- 3) If you enter a value for this function, you must also enter a value for the "Intermed. height" subfunction in another step.

- 4) This function is only displayed if the "Sim. off" option was not selected under the "Simulation" subfunction.
- 5) This function is only displayed if the "User-spec." option was selected under the "Customer unit" subfunction.
- 6) This function is only displayed if the "Horizontal cyl" or "Sphere" option was selected under the "Type" subfunction.
- 7) This function is only displayed if the "Pyramid bottom", "Conical bottom" or "Angled bottom" option was selected under the "Type" subfunction.
- 8) This function is only displayed if the "Table" option was selected under the "Type" subfunction.
- 9) This function is not displayed if the "Table" option was selected under the "Type" subfunction.

6.5.1 "Linearization" function

"Type" subfunction

Select the type of linearization in this subfunction.


Options:

■ "None"

In this type of linearization, the measured level is not converted but instead is output linearly in the level unit selected (see "Unit level" function).

■ "Linear"

In this type of linearization, the measured value output is linear to the measured level.



L00-FMI5xxxx-19-05-xx-xx-001


The following must be specified as additional parameters:

- The unit for the linearized value, e.g. kg, m³, ft³, ... ("Customer unit" subfunction)
- The maximum tank contents (a) measured in a customer unit ("Max. tank contents" subfunction)

Options:

- "Horizontal cyl."
- "Sphere"

In these types of linearization, the volume in a spherical tank or in a horizontal cylindrical tank is calculated from the level.



L00-FMI5xxxx-19-05-xx-xx-002


The following must be specified as additional parameters:

- The unit for the linearized value, e.g. kg, m³, ft³, ... ("**Customer unit**" subfunction)
- The diameter (D) of the cylindrical or spherical tank ("**Diameter**" subfunction)
- The maximum tank contents (a) measured in a customer unit ("**Max. tank contents**" subfunction)

Options:

- "Pyramid bottom"
- "Conical bottom"
- "Angled bottom"

In these types of linearization, the volume in the tank in question is calculated from the level measured.




L00-FMI5xxxx-19-05-xx-xx-003

The following must be specified as additional parameters:

- The unit for the linearized value, e.g. kg, m³, ft³, ... ("**Customer unit**" subfunction)
- The intermediate height H in accordance with the diagram above ("**Intermed. height**" subfunction)
- The maximum tank contents (a) measured in a customer unit ("**Max. tank contents**" subfunction)

Options:■ **"Table"**

In this type of linearization, the measured value is calculated using a linearization table. The table can comprise up to 32 "Level - Volume" value pairs. The table must be monotone.




L00-FMI5xxxx-19-05-xx-xx-004

The following must be specified as additional parameters:

- The unit for the linearized value ("**Customer unit**" subfunction)
- The linearization table ("**Edit**" subfunction)

"Mode" subfunction

In this function, specify whether the measurement should refer to level A or to the empty area B.



L00-FMI5xxxx-19-05-xx-xx-005

"Simulation" subfunction

In this subfunction, you can simulate the level or the volume by entering a level under "Sim. level value" or a volume under "Sim. vol. value".

"Sim. level value" or "Sim. vol. value" subfunction

In this subfunction, you can enter the level or volume value to be simulated.

6.5.2 "Linearization" function**"Customer unit" subfunction**

In this function, enter the desired unit for the linearized values (e.g. kg, m³, ft³, ...).

"Customized text" subfunction

In this function, enter your specific name for the unit. The measured value indicated in the main screen will then be displayed in this unit.

"Diameter" subfunction

In this subfunction, specify the diameter of the horizontal cylindrical tank or the spherical tank (only for the "dry" type of basic setup).

"Intermed. height" subfunction

In this function, specify the intermediate height H (see graphic -> options: "Pyramid bottom", "Conical bottom", "Angled bottom") of the container in question.
The probe length L1 must be entered here in the event of a wet calibration.

"Edit" subfunction


Use this function to enter, modify or read the linearization table.
The following options are available:

- "Read"
The table editor is opened. The existing table can be read but not edited.
- "Manual"
The table editor is opened. Table values can be entered or modified.
- "Semi-automat."
The table editor is opened. The level value is read in automatically.
The related measured value (volume, weight or flow) must be entered by the user.
- "Delete"
The linearization table is deleted.



Note!
The linearization table can only be edited if it is disabled ("Status" subfunction)

The table editor



L00-FMI5xxxx-19-05-xx-en-013

"Status table" subfunction

In this function, you can specify whether the linearization table should be used or not.

Options:**■ "Enabled"**

The table is used.


■ "Disabled"

The table is not used. The measured value is output linearly with regard to the level unit.

"Max. scale" subfunction

In this function, specify the maximum contents of the tank in question in the customer unit.

6.6 "Output" menu



Output/calculat.	01302
extended calibr.	
HART setting	
Simulation	

You can make the following settings in the "Output" menu:

Menu	Submenu	Function	Subfunction	Function value
	 	 		
Output	Extended calibr.	Extended calibr.	Measuring range	2000 pF¹⁾ 4000 pF
			Sensor DAT Stat.	OK
			Sensor DAT	Upload Download
		Output/Calculat	Curr. turn down	On Off
			Turn down 4 mA ²⁾	0 %
			Turn down 20 mA ²⁾	100 %
			4 mA threshold	On Off
	HART setting	HART setting	HART address	0
			No. of preambles	5
			Short TAG HART	TAG
		Output/Calculat	Current span	4 to 20 mA Fix. curr. HART
			mA value ³⁾	4 mA
	Simulation	Simulation		Off On
			Simulation value ⁴⁾	xx.xx mA

- 1) Factory settings are marked in "bold".
- 2) This function is only displayed if the "On" option was selected under the "Curr. turn down" subfunction.
- 3) This function is only displayed if the function value "Fix. curr. HART" was selected under the "Current span" subfunction.
- 4) This function is only displayed if the "On" option was selected under the "Simulation" function.

6.6.1 "Extended calibr." submenu

"Extended calibr." function

In this function, you can specify the measuring range.

"Measuring range" subfunction

Specify the measuring range in this subfunction.

- C_A = 0 to 2000 pF (< 6 m probe length)
- C_A = 0 to 4000 pF (> 6 m probe length)



Note!
At the factory, the measuring range is always calibrated to the probe length ordered. If the electronic insert is used in another probe, the measuring range must be configured in accordance with the probe length.

"Output/Calculat." function*"Sensor DAT stat." subfunction*

This subfunction shows the status of the sensor DAT.

- OK (Sensor DAT is ready for use).
- Error (Sensor DAT is not ready for use ore or missing).

"Sensor DAT" subfunction

Calibration values can be transmitted with this function. A distinction is made between two types:

- The sensor has been replaced and the electronic insert should continue to be used.
- The electronic insert has been replaced but the sensor should continue to be used.

For instances of this nature, the calibration values already set can be transferred from the sensor to the electronic insert or from the electronic insert to the sensor.

Upload

To transfer the calibration values from the sensor to the electronic insert.

Download

To transfer the calibration values from the electronic insert to the sensor.

"Curr. turn down" subfunction

With this function, you can switch on the current turn down. The current output then only refers to a (freely definable) part of the measuring range. This is then magnified when displayed.

"Curr. turn down" subfunction (not available for "Current span", "Fix. curr. HART")


With this function, you can switch on the current turn down. The current output then only refers to a (freely definable) part of the measuring range. This is then magnified when displayed.

"Turn down 4 mA" subfunction (only for "Curr. turn down", "On")

In this function, enter the measured value at which the current should be 4 mA.

"Turn down 20 mA" subfunction (only for "Curr. turn down", "On")

In this function, enter the measured value at which the current should be 20 mA.



L00-FMI5xxxx-19-05-xx-xx-009

A: Turn down 4 mA; B: turn down 20 mA

"4 mA threshold" subfunction (for "Current span" = "4 to 20 mA")

You can switch on the 4 mA threshold in this subfunction. The 4 mA threshold means that the current never undershoots 4 mA even if the measured value is negative.


Options:

■ **"Off"**

The threshold is switched off. Currents under 4 mA can occur.

■ **"On"**

The threshold is switched on. The current never undershoots 4 mA.



L00-FMI5xxxx-19-05-xx-xx-010

A: 4 mA threshold off; B: 4 mA threshold on

6.6.2 "HART setting" submenu

"HART settings" function"

"HART address" subfunction

In this subfunction, specify the HART communication address for the device.

Possible values:

- For standard operation: **0**
- For multidrop operation: **1 - 15**



Note!

In multidrop operation, the output current is 4 mA as standard. However, it can be changed in the "mA value" function.

"No. of preambles" subfunction

In this subfunction, specify the number of preambles for the HART protocol. It might make sense to increase the value if there are communication problems on the lines.

"Short TAG HART" subfunction

Here, you can enter the TAG name for HART communication in the device.

Output/Calculat" function."

"Current span" subfunction

In this subfunction, select the current span to which the measuring range should be mapped.


Options:

■ **"4 to 20 mA"**

The measuring range (0 % to 100 %) is mapped to the 4 to 20 mA current span.

■ **"Fix. curr. HART"**

A fixed current is output. Its value can be specified in the "mA value" subfunction. The measured value is only transmitted via the HART signal.



L00-FMI5xxxx-19-05-xx-xx-011

A: Current span = 4 to 20 mA; B: current span = fix. curr. HART; C: mA value

6.6.3 "Simulation" submenu

"Simulation" function

"Simulation" subfunction

With this function, you can switch the simulation of an output current on and off.

Options:

■ "Off"

Simulation does not take place. Instead, the device is in the measuring mode.

■ "On"

The device is in the simulation mode. A measured value is not output. Instead, the current output assumes the value defined in the "Simulation value" subfunction.

"Simulation value" subfunction (only for "Simulation", "On")

Specify the current value to be simulated in this function.

6.7 "Device properties" menu

You can make the following settings in the "Device properties" menu:

Menu	Submenu	Function	Subfunction	Function value
	 	 		
Device properties	Display	Language		English Deutsch Francais Espanol Italiano Nederlands
			Display format	Format
				Decimal ft-in-1/16"
			No of decimals	x x.x x.xx x.xxx
			Sep. character	. (dot) ,
			Back to home	900 s
		Actual error	Actual error 1	
			Actual error 2	
			Actual error 3	
		Last error	reset errorlist	Keep Delete
			Last error 2	...
			Last error 3	...
	Diagnostics	Password/reset	Reset	12345
			Status	Unlocked
		Electronic temp.	Electronic temp.	xx.x °C
			Max. temp.	xx.x °C
			Min. temp.	xx.x °C
			Temperature unit	°C °F K
		Min/Max temp.		Keep Delete Reset Min. Reset Max.
			Measure capacity	xxxx.xx pF
			Max. capacity val	xxxx.xx pF
			Min. capacity val	xxxx.xx pF
			Min/Max capacity	Keep Delete Reset Min. Reset Max.
	System parameters	Device information	Device designation	Liquicap-FMI5x
			Serial No.	...
			EC Serial No.	xxxxxxxxxxx
			Device marking	FMI51- OrderCode
		Device information	Dev. rev	x
			Software version	V01.xx.xx.xxx
			DD version	xx
		Device information	Working hour	xxxxx h
			Current run time	000d00h00m
	Probe length	Probe length	Probe length	xxx mm
			Sensitivity	0.0

6.7.1 "Display" submenu

"Language" function

In this function, select the language for the display and operating module.

Options:

- "English"
- "Deutsch"
- "Français"
- "Español"
- "Italiano"
- "Nederlands"

"Display format" function

The "Display format" refers to how the measured value is displayed.

"Format" subfunction

In this subfunction, select the display format for displaying numbers.

Options:

- "Decimal"
- "ft-in-1/16"

"No. of decimals" subfunction

In this subfunction, select the number of places after the decimal point for displaying numbers.

Options:

- "x"
- "x.x"
- "x.xx"
- "x.xxx"

"Sep. character" subfunction

In this function, select the separator for displaying decimal numbers.

Options:

- "Dot (.)"
- "Comma (,)"

6.7.2 "Diagnosis" submenu

"Actual error" function

With this function, you can call up a list of the errors currently pending. The errors are arranged by priority. If you select an error, a text field appears with a brief description of the error (e.g. probe incorrectly calibrated, operating temperature too high, electronics error), (see also "Error code list" in Section 9, "Troubleshooting").

"Last error" function

With this function, you can call up a list of the errors last rectified. You also have the option of resetting the error list (with "reset errorlist"). This overwrites the last three error codes with 0.

"Password/reset" function

With this function, you can restore the factory settings. All parameters are reset to their factory setting.

"Reset" subfunction

In this subfunction, enter the reset code ("333" or "7864") to reset all the parameters to their factory setting.

- The factory settings of the parameters are marked in bold in the menu overview.
- During a "333" reset, linearization is reset to "linear". However, any linearization table available is retained and can be activated again where necessary.
The following subfunctions (marked with an asterisk (*)) are also reset.
- During a "7864" reset, linearization is reset to "linear" and the linearization table deleted.

"Electronic temp." function

In this function, you can have temperatures displayed that were measured by the electronic insert during operation.

*"Electronic temp." subfunction **

This subfunction displays the electronics temperature currently measured.

*"Max. temp." subfunction **

This subfunction displays the highest temperature value measured by the device.

"Min. temp." subfunction

This subfunction displays the lowest temperature value measured by the device.

"Temperature unit" subfunction

In this subfunction, you can determine the unit in which the temperature should be displayed. The following options are available:

- "°C"
- "°F"
- "K"

"Min/Max temp." subfunction

In this subfunction, you delete or individually reset the "Min. or Max. temp".

"Measure capacity" function

In this function, you can have measuring capacities displayed that were measured by the electronic insert during operation.

"Measure capacity" subfunction

This subfunction displays the measuring capacity currently measured.

*"Max. capacity val." subfunction **

This subfunction displays the highest capacitance value measured by the device.

*"Min. capacity val." subfunction **

This subfunction displays the lowest capacitance value measured by the device.

"Min/Max capacity" subfunction

In this subfunction, you delete or individually reset the "Min. or Max. capacity".

6.7.3 "System parameters" submenu



Note!

All functions listed below can be viewed only.

"Device information" (I) function

In this function, device information, with which the device can be identified, can be displayed.

"Device marking" subfunction

This subfunction displays the device name (e.g. Liquicap M-FMI51).

"Serial No." subfunction

This subfunction displays the serial number of the device that was assigned in the factory.

"EC Serial No." subfunction

This subfunction displays the serial number of the electronic insert.

"Device marking" subfunction

This subfunction displays the device marking and the order code.

"Dev. rev" subfunction

This subfunction displays the version of the electronic hardware.

"Software version" subfunction

This subfunction displays the software version of the device that was assigned in the factory.

"DD version" subfunction

This function indicates the DD version with which this device can be operated using FieldCare.

"Working hour" subfunction

This subfunction displays the number of operating hours.

"Current run time" subfunction

This subfunction displays the "current run time" of the device. The first three digits display the number of days, followed by "d". The next two digits display the hours, followed by "h". The last two digits indicate the minutes.

"Probe length" function

In this function, more probe information can be displayed.

"Probe length" subfunction

You can read off the current probe length in this subfunction.

Probe length = L1 – (thread length – plug)

See also "Empty calibration" → 52.

"Sensitivity" subfunction

You can read off the current sensitivity in mm/pF in this subfunction.

6.8 Operation

After Basic setup, Liquicap M outputs the measured value via

- the display and operating module
- the current output
(the entire measuring range (0 % to 100 %) is then mapped to the range (4 to 20 mA) of the current output.
- the digital HART signal.

6.9 FieldCare: operating program from Endress+Hauser

The FieldCare operating program is Endress+Hauser's plant asset management tool based on FDT technology. You can use FieldCare to configure all Endress+Hauser devices as well as third-party devices which support the FDT standard. The following operating systems are supported: Windows 2000, Windows XP and Windows Vista.

FieldCare supports the following functions:

- Configuration of transmitters in online operation
- Tank linearization
- Loading and saving device data (upload/download)
- Documentation of the measuring point

Connection options:

HART via Commubox FXA195 and the USB port of a computer



Note!

After reinstalling FieldCare, or by clicking a link in the Help menu, a video can be activated that explains the possible applications of the program in just a few minutes.



[Getting Started \(Help\)](#)

- Create or Update DTM Catalog
- Connect to Devices
 - HART FSK Modem (FXA191, FXA195)
 - FieldGate FXA720 (PROFIBUS)
 - FieldGate FXA520 (HART)

[Getting Started \(Video\)](#)

- FieldCare in a few minutes

[Continue](#)


☒ Show start-up screen

Endress+Hauser 
People for Process Automation


Startup_screen_de.tif


6.9.1

Menu-guided commissioning:



Basic setup:






6.9.2 Interface measurement

If there are different media in the container (e.g. water and oil), the capacitance values for "Empty calibration" and "Full calibration" can be calculated.

CapCalc.xls is a capacitance calculation program in FieldCare which can be used to calculate the calibration values for level measurement and interface measurement.



- 1.) e.g. water (the medium must be conductive $\geq 100 \mu\text{S}/\text{cm}$)
 2.) emulsion
 3.) e.g. oil (nonconductive medium $< 1 \mu\text{S}/\text{cm}$ and $\text{DC} < 5$)

L00-FMI5xxxx-15-05-xx-xx-000

The program calculates the calibration values on the basis of the data entered (e.g. probe length, probe type, medium properties etc.). The secure functioning of interface measurement can already be determined at this time.

The calculated calibration values can be transmitted to the FEI50H electronic insert via the display or Fieldcare.




Note!

Generally speaking, capacitance interface measurement is also suitable for very pronounced emulsion layers. The emulsion layer average is always measured.


6.9.3 Dry calibration for interface measurement

Calculating the calibration data with CapCalc

Click the CA button in the tool bar to start CapCalc.




In the dialog that follows, click the "Activate macros" button.



L00-FMIxxxx-20-00-00-en-018


In the window that follows, click the [Next] button in the top right.



L00-FMIxxxx-20-00-00-en-019

Editing the probe and application-specific data

Endress+Hauser GmbH+Co. KG Hauptstraße 1 79689 Maulburg Germany		Endress+Hauser  People for Process Automation		Sprache wählen Select language
Customer: Muster GmbH+Co. KG Customer-No.: X0815 Street: Musterstraße 5 ZIP-Code/Town: 12345 Musterstadt		Attention: Hans Mustermann Phone: 0815 - 12345 Fax: 0815 - 6789 Reference: Trennschichtmessung Tag: 1122334455		19.01.2007 Print Info

Probe type FMI51, rod 10mm, PTFE or PFA Probe diameter: 8 mm Probe diameter with isolation: 10 mm DC-value of isolation: 1,9 Base capacity: 27,07 pF Auxiliary capacities: 0 pF		Probe type
Probe length L1: 1000 mm inactive length L3: 0 mm Value Empty E: 1000 mm Value Full F: 500 mm Wall distance: 250 mm		Auxiliary capacities
Medium top Name: oil Conductivity: 0,01 µS/cm Dielectric constant: 2,1		DC handbook
Medium bottom Name: water Conductivity: 180 µS/cm Dielectric constant: 80,4		

Calibration data level

Calibration data interface measurement

L00-FMIxxxx-20-00-00-en-020

1. To select the probe type, click the "Probe type" button.
2. The probe data (L1 and L3) can be found on the nameplate of the probe. Enter these data accordingly.
3. Enter the application-specific data such as "Value empty" and "Value full" and "Wall distance" in accordance with the application.
4. In the "Medium top" and "Medium bottom" fields, enter the conductivity and the DC value of the medium.
5. To obtain the capacitance values for the calibration, click the "Calibration data interface measurement" button. The capacitance values for empty calibration and full calibration are calculated and displayed as a result.

If the medium properties are not known, you can use the "DC handbook" button to transfer the DC values and the conductivity of the corresponding media to the calculation program.

6.9.4 Wet calibration for interface measurement

This chapter describes the wet calibration procedure for "Empty calibration" and "Full calibration".

"Empty calibration"

1. Fill the container with the top medium and perform "Empty calibration" 0 % (see basic setup →  48)
If it is not possible to fill with medium, "Empty calibration" can also be performed with the probe exposed (in the air). A calibration inaccuracy of approx. 2.5 % per meter should be expected here (oil and water are the reference media).

"Full calibration"

2. Fill the container with the bottom medium and perform "Full calibration" 100 % (see basic setup →  48)

You have now performed basic setup.

6.9.5 Empty and full calibration completed

You have now performed empty and full calibration and saved the values in the electronic insert and the sensor DAT.

7 Maintenance

No special maintenance work is required for the Liquicap M level transmitter.

External cleaning

When externally cleaning Liquicap M, make sure that the cleaning agent used does not attack or corrode the housing surface or seals.

Cleaning the probe

Depending on the application, buildup (contamination and soiling) can form on the probe rod. A high degree of material buildup can affect the measurement result. If the medium tends to create a high degree of buildup, regular cleaning is recommended. When hosing down or during mechanical cleaning, it is important to make sure that the insulation of the probe rod is not damaged. If cleaning agents are used make sure the material is resistant to them!

Seals

The process seals of the sensor should be replaced periodically, especially when using molded seals (aseptic version)! The intervals between seal replacement depend on the frequency of the cleaning cycles and on the fluid and cleaning temperature.

Repair

The Endress+Hauser repair concept is devised in such a way that the devices have a modular design and repairs can be carried out by the customers.

Spare parts are grouped into handy kits with related replacement instructions. The "Spare parts" section lists all the spare part kits, including the order numbers, which you can order from Endress+Hauser for repairing Liquicap M. For further information on service and spare parts, please contact Endress+Hauser Service.

Repairing Ex-certified devices

The following information also has to be taken into account when repairing Ex-certified devices:

- Ex-certified devices may only be repaired by experienced, skilled staff or by Endress+Hauser Service.
- Applicable standards, national Ex-area regulations as well as the Safety Instructions (XA) and certificates must be observed.
- Only genuine spare parts from Endress+Hauser may be used.
- When ordering spare parts, please note the device designation on the nameplate. Parts can only be replaced by the same parts.
- Repairs must be carried out in accordance with the instructions. Following a repair, the individual testing specified for the device must be carried out.
- Certified devices can only be converted to other certified device versions by Endress+Hauser Service.
- Every repair and conversion made to the device must be documented.

Replacement

After replacing a Liquicap M or the electronic insert, the calibration values must be transferred to the replacement device.

- When the probe is replaced, the calibration values in the electronic insert can be transferred to the sensor DAT (EEPROM) module via a manual download.
- When the electronic insert is replaced, the calibration values of the sensor DAT (EEPROM) module can be transferred to the electronics via a manual upload.

This means that you can restart the device without having to carry out a new calibration. (→  47 Sensor DAT (EEPROM) Upload/download.)

8 Accessories

8.1 Protective cover

For F13 and F17 housing
Order number: 71040497

For F16 housing
Order number: 71127760

8.2 Shortening set for FMI52

For Liquicap M FMI52 (no hygienic approval: EHEDG, 3A)
Order number: 942901-0001

8.3 Commubox FXA195 HART

For intrinsically safe HART communication with FieldCare via the RS232C interface or USB.

8.4 HAW56x surge arrester

Surge arrester for limiting overvoltage in signal lines and components: see Technical Information TI00401F.

8.5 Weld-in adapter

All the weld-in adapters available are described in the document TI00426F.
This is available in the Download Area of the Endress+Hauser web site: www.endress.com
→ Download

9 Troubleshooting

The operating status of the device is indicated by the LEDs on the electronic insert.

9.1 Error messages at electronic insert

9.1.1 Green LED flashing

Green LED (Φ indicates operation):

- Flashes every 5 s:
 - Indicates whether the device is operational
- Flashes once every s:
 - The device is in the calibration mode
- Flashes 4 times:
 - The device confirms a parameter change (function switch position 4, 5, 6)

9.1.2 Red LED flashing ($\downarrow$ indicates a fault)

Warning

- Flashes five times a s:
 - Capacitance at probe is too large
 - Probe insulation break detection
 - FEI50H is defective

The reasons for warnings include:

Alarm

- Flashes once every s:
 - The temperature in the electronic insert is outside the permitted temperature range.



Note!

For more accurate error analysis, see → 81 "Error codes".

9.2 System error messages

9.2.1 Error signal

Errors occurring during commissioning or during operation are displayed as follows:

- Error symbol, error code and error description on the display and operating module.
- Current output, can be configured ("Output on alarm" function)
 - MAX, 110 %, 22 mA
 - Hold (last value is retained)
 - User-spec. value

9.2.2 Last errors

With the "Last error" function ("System information" function group, "Error list" submenu), you can call up a list of the errors last rectified.

9.2.3 Types of error

Type of error	Display symbol	Meaning
Alarm (A)	 Permanent	The output signal assumes a value that can be specified with the "Output on alarm" function: ■ MAX: 110 %, 22 mA ■ Hold: Last value is retained ■ User-spec. value In addition, an error message is also shown on the display.
Warning (W)	 Flashing	The device continues measuring. An error message is shown on the display.

9.2.4 Error codes

The error codes shown on the display are 4-digit codes:

- Position 1: Type of error
 - ? A = Alarm
 - ? W = Warning
- Positions 2-4:
 - Refer to the error in accordance with the following table

Example:

A 116	■ A: Alarm ■ 116: Download error
-------	---

Code	Error description	Remedial action
A 101, A 102, A 110, A 152	Checksum error	Total reset and recalibration necessary
W 103, W153	Initializing - please wait	Replace the electronics if the message does not disappear after a few seconds
A 106	Downloading - please wait	Wait until the downloading is complete
A 111, A 112, A 113, A 114, A 115, A 155, A 164, A 171, A 404, A 405, A 407, A 408, A 409, A 410, A 411, A 412, A 413, A 414, A 415, A 416, A 417, A 418, A 421, A 422, A 423, A 424,	Electronics defective	Switch device off/on; if the error persists, Contact Endress+Hauser-Service
A 116	Download error	Repeat download or perform a total reset
A 426	Data of Sensor-DAT (EEPROM) not consistent	Repeat download from electronic insert or perform a total reset
A 427	Hardware not recognized after replacement	Repeat download or perform a total reset.
A 1121	Current output not calibrated	Contact Endress+Hauser-Service
W 153	Initializing	Replace the electronics if the message does not disappear after a few seconds
A 400	Measured capacitance too high	Change measuring range, verify probe



Code	Error description	Remedial action
A 403	Measured capacitance too low	Verify probe
A 420	No sensor DAT (EEPROM) available	Exchange sensor
A 428	Probe insulation break detection	Verify probe
W 425	Warning insulation defective	Check insulation
W 429	Proof test active	Wait until the proof test is completed
W 1601	Linearization curve not monotone for level	Re-enter linearization
A 1604	Calibration faulty	Correct calibration
W 1611	Level linearization points	Enter additional linearization points
W 1662	Temperature at electronic insert too high (max. temp. at sensor exceeded)	Lower ambient temperature by suitable measures
W 430	Data of probe and electronic insert not compatible	Check probe, perform a total reset
W 1671	Linearization table entered incorrectly	Readjust table
W 1681	Current outside measuring range	Perform basic setup; Check linearization
W 1683	Current turn down calibration faulty	Repeat calibration
W 1801	Level simulation switched on	Switch off level simulation
W 1802	Simulation switched on	Switch off simulation
W 1806	Current output is in simulation mode	Set current output to normal mode
W 511	Electronic insert has lost calibration data	Contact Endress+Hauser service



Note!

If none of the proposed remedial measures achieves the desired result, perform reset 2
→ 46.

9.3 Possible measuring errors

Error	Remedial measures
Measured value is incorrect	1. Verify empty and full calibration. 2. Clean probe if necessary, verify probe 3. If necessary, alter better installation position of probe (do not mount in filling curtain) 4. Check ground from process connection to tank wall. Resistance measurement $< 1 \Omega$ 5. Check probe insulation (resistance measurement) $> 800 \text{ k}\Omega$ (only possible for conductive media) F16 housing  Electronic insert FEI50H  BA298Fen090
If the surface is turbulent, the measured value jumps sporadically to higher levels	Increase output damping

9.4 Spare Parts

The URL for the W@M Device Viewer (www.endress.com/deviceviewer):

There, all spare parts for the measuring device are listed, including the order code, and can be ordered. If available, the corresponding Installation Instructions can also be downloaded there.

9.5 Return

The measuring device must be returned if it is need of repair or a factory calibration, or if the wrong measuring device has been delivered or ordered. Legal specifications require Endress+Hauser, as an ISO-certified company, to follow certain procedures when handling products that are in contact with the medium.

To ensure safe, swift and professional device returns, please refer to the procedure and conditions for returning devices provided on the Endress+Hauser website at

<http://www.endress.com/support/return-material>

9.6 Disposal

When disposing of the device, make sure the device components are separated based on the materials used and recycled where possible.

9.7 Software history

Software-Version / Date	Software updates	Documentation
FW: V 01.00.xx / 08.2005	Original-Software. Operable with: FieldCare, version 2.08.00 and higher	-
FW: V 01.03.xx / 02.2007	Expansion feature suitable for SIL 2 applications	

10 Technical data

10.1 Technical data: probe

10.1.1 Capacitance values of the probe

- Basic capacitance: approx. 18 pF

10.1.2 Additional capacitance

- Mount the probe at a minimum distance of 50 mm from a conductive container wall:
Probe rod: approx. 1.3 pF/100 mm in air
Probe rope: approx. 1.0 pF/100 mm in air
- Fully insulated probe rod in water:
Approx. 38 pF/100 mm (16 mm rod)
Approx. 45 pF/100 mm (10 mm rod)
Approx. 50 pF/100 mm (22 mm rod)
- Insulated probe rope in water: approx. 19 pF/100 mm
- Rod probe with ground tube:
 - Insulated probe rod: approx. 6.4 pF/100 mm in air
 - Insulated probe rod: approx. 38 pF/100 mm in water (16 mm rod)
 - Insulated probe rod: approx. 45 pF/100 mm in water (10 mm rod)

10.1.3 Probe lengths for continuous measurement in conductive liquids

- Rod probe (range 0 to 2000 pF at ≤ 4000 mm)
- Rope probe < 6 m (range 0 to 2000 pF)
- Rope probe > 6 m (range 0 to 4000 pF)

10.2 Input

10.2.1 Measured variable

Continuous measurement of change in capacitance between probe rod and container wall or ground tube, depending on the level of a liquid.

Probe covered $\Rightarrow$ high capacitance

Probe not covered $\Rightarrow$ low capacitance

10.2.2 Measuring range

- Measuring frequency: 500 kHz
- Span: $\Delta C = 25$ to 4000 pF recommended (2 to 4000 pF possible)
- Final capacitance: $C_E = \text{max. } 4000$ pF
- Adjustable initial capacitance:
 - $C_A = 0$ to 2000 pF (< 6 m probe length)
 - $C_A = 0$ to 4000 pF (> 6 m probe length)


10.2.3 Measuring condition

- Measuring range L1 possible from the tip of the probe to the process connection.
- Particularly suited for small containers.

Note!

When installing in a nozzle, use inactive length (L3).

The 0 %, 100 % calibration can be inverted.



L00-FMI5xxxx-15-05-xx-xx-002

Dimensions mm (in)

10.3 Output

10.3.1 Output signal

FEI50H (4 to 20mA/HART version 5.0)

3.8 to 20.5 mA with HART protocol

10.3.2 Signal on alarm

Fault diagnosis can be called up via:

- Local display: Red LED
- Local display showing:
 - Error symbol
 - Plain text display
- Current output: 22 mA
- Digital interface: HART status error message

10.3.3 Linearization

The Liquicap M linearization function enables conversion of the measured value into any desired length or volume units. Linearization tables for volume calculation of horizontal cylindrical tanks and spherical tanks are pre-programmed. Any other tables with up to 32 value pairs can be input manually or semi-automatically.

10.4 Performance characteristics

10.4.1 Reference operating conditions

- Room temperature: +20 °C ±5 °C
- Span
 - Standard measuring range: 5 to 2000 pF
 - Extended measuring range: 5 to 4000 pF
 - Span for reference: 5 to 4000 pF (corresponds to approx. 1 m probe length)
- Non-repeatability (reproducibility) as per DIN 61298-2: max. ±0.1 %
- Non-linearity for limit point setting (linearity) as per DIN 61298-2: max. ±0.25 %

10.4.2 Maximum measured error

- Linearity: 0.5 %
- Reproducibility: 0.1 %

10.4.3 Influence of ambient temperature

< 0.06 %/10 K related to the full scale value


10.4.4 Switch-on behavior

14 s (stable measured value after switch-on procedure). Start-up in safe status (22mA).

10.4.5 Measured value reaction time

Operating mode: $t_1 \leq 0.3$ s

SIL operating mode: $t_1 \leq 0.5$ s



τ = Output damping
 t_1 = Dead time

10.4.6 Output damping

$\tau = 1$ s (factory setting) 0 to 60 s can be set.

The output damping affects the speed at which the display and the current output react to changes in the level.

10.4.7 Accuracy of factory calibration

	Probe length < 2 m	Probe length > 2 m
Empty calibration (0 %), Full calibration (100 %)	typically ≤ 5 mm	typically ≤ 2 %

Reference conditions for the factory calibration:


- Medium conductivity $\geq 100 \mu\text{S}/\text{cm}$
- Minimum distance to tank wall = 250 mm



Note!

In an installed state, recalibration is only necessary if:

- The 0 % or the 100 % values have to be adjusted specifically for customer
- The liquid is not conductive.
- The probe distance to the tank wall is < 250 mm



L00-FMI5xxxx-15-05-xx-xx-002

10.4.8 Resolution

Analog in % (4 to 20 mA)

- FMI51, FMI52: 11 bit/2048 steps, 8 μ A
- The resolution of the electronics can be directly converted to units of length of the probe FMI51 or FMI52. For example, active probe rod 1000 mm.

$$\text{Resolution} = 1000 \text{ mm} / 2048 = 0.48 \text{ mm}$$

10.5 Operating conditions: Environment

10.5.1 Ambient temperature range

- -50 to +70 °C
- -40 to +70 °C (with F16 housing)
- Observe derating → 89
- If operating outdoors, use a protective cover! → 79.

10.5.2 Storage temperature

-50 to +85 °C

10.5.3 Climate class

DIN EN 60068-2-38/IEC 68-2-38: Z/AD check

10.5.4 Vibration resistance

DIN EN 60068-2-64/IEC 68-2-64: 20 Hz– 2000 Hz; 0.01 g^2 /Hz

10.5.5 Shock resistance

DIN EN 60068-2-27/IEC 68-2-27: 30g acceleration

10.5.6 Cleaning

Housing:

When cleaning, make sure that the cleaning agent used does not attack or corrode the housing surface or seals.

Probe:

Depending on the application, buildup (contamination and soiling) can form on the probe rod. A high degree of material buildup can affect the measurement result. If the medium tends to create a high degree of buildup, regular cleaning is recommended. When hosing down or during mechanical cleaning, it is important to make sure that the insulation of the probe rod is not damaged.

10.5.7 Degree of protection

	IP66*	IP67*	IP68*	NEMA4X*
Polyester housing F16	X	X	-	X
Stainless steel housing F15	X	X	-	X
Aluminum housing F17	X	X	-	X
Aluminum housing F13 with gas-tight process seal	X	-	X***	X

	IP66*	IP67*	IP68*	NEMA4X*
Stainless steel housing F27 with gas-tight process seal	X	X	X***	X
Aluminum housing T13 with gas-tight process seal and separate connection compartment (EEx d)	X	–	X***	X
Separate housing	X	–	X***	X

* As per EN60529

** As per NEMA 250

*** Only with M20 cable entry or G1/2 thread

10.5.8 Electromagnetic compatibility (EMC)

- Interference emission to EN 61326, Electrical Equipment Class B
Interference immunity to EN 61326, Annex A (Industrial) and NAMUR Recommendation NE 21 (EMC)
Failure current is acc. NAMUR NE43: FEI50H = 22mA
- A usual commercial instrument cable can be used.

10.6 Operating conditions: Process

10.6.1 Process temperature range

The following diagrams apply for:


- Rod and rope version
- Insulation: PTFE, PFA, FEP
- Standard applications outside hazardous areas



Note!

The temperature is restricted to $T_a -40^\circ\text{C}$ if the polyester housing F16 is used or if additional option B is selected (free from paint-wetting impairment substances, only FMI51).

With compact housing




T_a : Ambient temperature

T_p : Process temperature

L00-FMI5xxxx-05-xx-xx-013

With separate housing



T_a = Ambient temperature

T_p = Process temperature

* The permitted ambient temperature at the separate housing is the same as indicated for the compact housing → 89.

Influence of process temperature

Error in case of fully insulated probes typically 0.13%/K related to the full scale value.

10.6.2 Process pressure limits

Probe ø10 mm (including insulation)

–1 to 25 bar

Probe ø16 mm (including insulation)

- –1 to 100 bar
- In the event of an inactive length, the maximum permitted process pressure is 63 bar
- In the event of CRN approval and inactive length, the maximum permitted process pressure is 32 bar.

Probe ø22 mm (including insulation)

–1 to 50 bar

Refer to the following standards for the pressure values permitted at higher temperatures:

- EN 1092-1: 2005 Table, Appendix G2
With regard to its resistance/temperature property, the material 1.4435 is identical to 1.4404 (AISI 316L) which is grouped under 13E0 in EN 1092-1 Tab. 18. The chemical composition of the two materials can be identical.
- ASME B 16.5a - 1998 Tab. 2-2.2 F316
- ASME B 16.5a - 1998 Tab. 2.3.8 N10276
- JIS B 2220

The lowest value from the derating curves of the device and the selected flange applies.


10.6.3 Pressure and temperature derating

For process connections ½", ¾", 1", flanges < DN50, < ANSI 2", < JIS 10K (10 mm rod)

For process connections ¾", 1", flanges < DN50, < ANSI 2", < JIS 10K (16 mm rod)

Rod insulation: PTFE, PFA

Rope insulation: FEP, PFA




P_p : Process pressure
 T_p : Process temperature

For process connections 1½", flanges ≥ DN50, ≥ ANSI 2", ≥ JIS 10K (16 mm rod)


Rod insulation: PTFE, PFA

Rope insulation: FEP, PFA



P_p : process pressure
 T_p : process temperature
 * For probes with an inactive length .

With a fully insulated inactive length (22 mm rod):



P_p : Process pressure
 T_p : Process temperature

10.7 Certificates and approvals

10.7.1 Other standards and guidelines

EN 60529

Degrees of protection by housing (IP code)

EN 61010

Protection measures for electrical equipment for measurement, control, regulation and laboratory procedures

EN 61326

Interference emission (Class B equipment), interference immunity (Annex A - Industrial).

NAMUR

Association for Standards for Control and Regulation in the Chemical Industry

IEC 61508

Functional safety

10.7.2 Other approvals

- See also → 93 ff.

- TSE Certificate of Suitability (FMI51)

The following applies to wetted device components:

- They do not contain any materials derived from animals.
- No additives or operating materials derived from animals are used in production or processing.

 Note!

The wetted device components are listed in Documentation TI00401F.

- AD2000

The wetted material (316L) corresponds to AD2000 – W0/W2

10.8 Documentation

10.8.1 Technical Information

- Liquicap M FMI51, FMI52
 TI00401F/00

10.8.2 Certificates

ATEX safety instructions

- Liquicap M FMI51, FMI52
ATEX II 1/2 G Ex ia IIC/IIB T3...T6, II 1/2 D IP65 T90 °C
XA00327F/00/A3
- Liquicap M FMI51, FMI52
ATEX II 1/2 G Ex d [ia] IIC/IIB T3...T6, Ex de [ia Ga] IIC/IIB T3...T6 Ga/Gb,
Ex iaD 20 Txx°C/Ex tD A21 IP6x Txx°C
XA00328F/00/A3
- Liquicap M FMI51, FMI52
Ga/Gb Ex ia IIC T6...T3; Ex ia D 20 / Ex tD A21 IP65 T90°C
XA00423F/00/A3
- Liquicap M FMI51, FMI52
II 3 G Ex nA/nC IIC T6; Ex tc IIIC T100 °C Dc
XA00346F/00/A3

INMETRO safety instructions

- Liquicap M FMI51, FMI52
Ex d [ia Ga] IIC/IIB T3...T6 Ga/Gb; Ex de [ia Ga] IIC T3...T6 Ga/Gb
XA01171F/00/A3
- Liquicap M FMI51, FMI52
Ex ia IIC/IIB T3...T6 Ga/Gb; Ex ia IIIC T90°C Da/Db IP65
XA01172F/00/A3

NEPSI safety instructions

- Liquicap M FMI51, FMI52
Ex ia IIC/IIB T3...T6 Ga/Gb
XA00417F/00/A3
- Liquicap M FMI51, FMI52
Ex d [ia] IIC/IIB T3/T4/T6 Ga/Gb, Ex de ia IIC/IIB T3/T4/T6
XA00418F/00/A3
- Liquicap M FMI51, FMI52
Ex nA IIC T3...T6 Gc, Ex nC IIC T3...T6 Gc
XA00430F/00/A3

Overfill protection DIBt (WHG)

- Liquicap M FMI51, FMI52
ZE00265F/00/de

Functional safety (SIL2)

- Liquicap M FMI51, FMI52
SD00198F/00/en

Control Drawings (CSA and FM)

- Liquicap M FMI51, FMI52
FM IS
ZD00220F/00/en
- Liquicap M FMI51, FMI52
CSA IS
ZD00221F/00/en
- Liquicap M FMI51, FMI52
CSA XP
ZD00233F/00/en

11 Operating menu

The main menu is activated by means of the right Enter key ↵.

The following menu headings appear. These are explained in more detail over the following pages:

- "Basic setup"
- "Safety set."
- "Linearization"
- "Output"
- "Device properties"

11.1 "Basic setup" menu Commissioning with display and operating module

You can make the following settings in the "Basic setup" menu.

Menu	Function	Subfunction	Function value
	 	 	
Basic setup	Basic setup	Medium property	no buildup ¹⁾ buildup
		Cal. type	Dry Wet
	Medium property ²⁾	Medium property	Conductive Nonconductive ³⁾ interface unknown
		DC value ⁴⁾	Value
		Unit level ⁵⁾	% (percentage) m mm ft inch
	Empty calibr.	Value empty	0 %
		Measure capacity	xxxx pF
		Confirm cal.:	Yes
	Full calibr.	Value full	100 %
		Measure capacity	xxxx pF
		Confirm cal.:	Yes
	Output damping	Output damping	1 s

- 1) Factory settings are marked in "bold".
- 2) This function is only displayed if the function value "Dry" was selected under the subfunction "Cal. type".
- 3) This function value can only be selected for probes with a ground tube.
- 4) This subfunction is only displayed if the function value "Nonconductive" was selected under the subfunction "Medium property".
- 5) This subfunction is only displayed if the function value "Nonconductive" or "Conductive" was selected under the subfunction "Medium property".

11.2 "Safety setting" menu

You can make the following settings in the "Safety settings" menu.

Menu	Function	Subfunction	Function value
	 	 	
Safety settings	Safety settings I	Code	100 ¹⁾
		Status	Unlocked Locked
	Safety settings II	Operating mode	Standard SIL/WHG
		Output damping	1 s
		Output 1	MAX
		Parameter okay	no Yes
	Safety settings III	Cap. empty	x,xx pF
		Value empty	x,xxx %
		Cap. full	2000.00 pF
		Value full	100.000 %
		Parameter okay	no Yes
	Operating mode	Operating mode	Standard SIL/WHG
		SIL op. mode ²⁾	Unlocked Locked
		Status	Unlocked Locked
	Output on alarm	Output	Max Hold User-spec.
		Output value ³⁾	xx.xx mA
	Proof test	Proof test	Off On

1) Factory settings are marked in "bold".

2) This subfunction is only displayed if the "SIL/WHG" option was selected under the "Operating mode" subfunction.

3) This subfunction is only displayed if the "User-specific" option was selected under the "Output" subfunction.

11.3 "Linearization" menu

You can do the following settings in the "Linearization" menu.

Menu	Function	Subfunction	Function value	Additional function values
	 	 		
Linearization	Linearization	Type	None	
			Linear ¹⁾	
			Horizontal cyl ²⁾	
			Sphere ²⁾	
			Pyramid bottom ³⁾	
			Conical bottom ³⁾	
			Angled bottom ³⁾	
			Table	
		Mode	level	
			Ullage	
		Simulation	Sim. off	
			Sim. level	
			Sim. volume	
		Sim. level value ⁴⁾ or Sim. vol. value ⁴⁾	xx.x % xx.x %	
	Linearization	Customer unit	% (percentage), l, hl, m3, dm3, cm3, ft3, usgal, igal, kg, t, lb, ton, m3, ft3, mm, inch, user-spec.	
		Customized text ⁵⁾	...	
		Diameter ⁶⁾	xxxx m	
		Intermed. height ⁷⁾	xx m	
		Edit ⁸⁾	Read	Table No.: 1 Input level: x m Input volume: %
			Manual	Table No.: 1 Input level: x m Input volume: %
			Semi-automat.	Table No.: 1 Input level: x m Input volume: %
			Delete	
		Status table ⁷⁾	Enabled Disabled	
		Max. scale ⁹⁾	100 %	

- 1) Factory settings are marked in "bold".
- 2) If you enter a value for this function, you must also enter a value for the "Diameter" subfunction in another step.
- 3) If you enter a value for this function, you must also enter a value for the "Intermed. height" subfunction in another step.
- 4) This function is only displayed if the "Sim. off" option was not selected under the "Simulation" subfunction.
- 5) This function is only displayed if the "User-spec." option was selected under the "Customer unit" subfunction.
- 6) This function is only displayed if the "Horizontal cyl" or "Sphere" option was selected under the "Type" subfunction.
- 7) This function is only displayed if the "Pyramid bottom", "Conical bottom" or "Angled bottom" option was selected under the "Type" subfunction.
- 8) This function is only displayed if the "Table" option was selected under the "Type" subfunction.
- 9) This function is not displayed if the "Table" option was selected under the "Type" subfunction.

11.4 "Output" menu

You can do the following settings in the "Output" menu.

Menu	Submenu	Function	Subfunction	Function value
	 	 		
Output	Extended calibr.	Extended calibr.	Measuring range	2000 pF¹⁾ 4000 pF
			Sensor DAT Stat.	OK
			Sensor DAT	Upload Download
		Output/Calculat	Curr. turn down	On Off
			Turn down 4 mA ²⁾	0 %
			Turn down 20 mA ²⁾	100 %
			4 mA threshold	On Off
	HART setting	HART setting	HART address	0
			No. of preambles	5
			Short TAG HART	TAG
		Output/Calculat	Current span	4 to 20 mA Fix. curr. HART
			mA value ³⁾	4 mA
	Simulation	Simulation		Off On
			Simulation value ⁴⁾	xx.xx mA

1) Factory settings are marked in "bold".

2) This function is only displayed if the "On" option was selected under the "Curr. turn down" subfunction.

3) This function is only displayed if the function value "Fix. curr. HART" was selected under the "Current span" subfunction.

4) This function is only displayed if the "On" option was selected under the "Simulation" function.

11.5 "Device properties" menu

You can do the following settings in the "Device properties" menu.

Menu	Submenu	Function	Subfunction	Function value
	 	 		
Device properties	Display	Language		English Deutsch Francais Espanol Italiano Nederlands
			Display format	Format
				Decimal ft-in-1/16"
			No of decimals	x x.x x.xx x.xxx
			Sep. character	. (dot) ,
			Back to home	900 s
		Actual error	Actual error 1	
			Actual error 2	
			Actual error 3	
		Last error	reset errorlist	Keep Delete
			Last error 2	...
			Last error 3	...
	Diagnostics	Password/reset	Reset	12345
			Status	Unlocked
		Electronic temp.	Electronic temp.	xx.x °C
			Max. temp.	xx.x °C
			Min. temp.	xx.x °C
			Temperature unit	°C °F K
		Min/Max temp.		Keep Delete Reset Min. Reset Max.
		Measure capacity	Measure capacity	xxxx.xx pF
			Max. capacity val	xxxx.xx pF
			Min. capacity val	xxxx.xx pF
			Min/Max capacity	Keep Delete Reset Min. Reset Max.
	System parameters	Device information I	Device designation	Liquicap-FMI5x
			Serial No.	...
			EC Serial No.	xxxxxxxxxxx
			Device marking	FMI51- OrderCode
		Device information	Dev. rev	x
			Software version	V01.xx.xx.xxx
			DD version	xx
		Device information III	Working hour	xxxxx h
			Current run time	000d00h00m
		Probe length	Probe length	xxx mm
			Sensitivity	0.0

Index

Numerics

4 mA threshold 66

A

Accessories 79

Actual error 69

Aligning the housing 20

B

Basic setup 43, 48, 50

C

Cable specification 22

Cal. type 50

Calibration error 83

Cap. empty 52, 55

Cap. full 55

CapCalc 51, 74

Carrying out empty calibration 44

Certificates and approvals 92

Code 54

Commissioning 43

Commubox 79

Commubox FXA191/195 HART 79

Confirm cal. 51

..... 24, 26

Conn. turn down 65

Current run time 71

Current span 66

Customer unit 61

Customized text 62

D

DC value 50

DD version 71

Designated use 4

Dev. rev 71

Device designation 71

Device information 71

Device marking 71

Device properties 48, 68

Diagnostics 69

Diameter 62

Display and operating elements (FEI50H) 28

Display and operating module 29, 48

Display format 69

Display symbols 29

Disposal 84

Download/upload sensor DAT 47

Dry calibration 48

Dry calibration for interface measurement 75

E

EC Serial No. 71

Edit 62

Editing functions with the picklist 36

Editing numeric functions 37

Electrical symbols 5

Electromagnetic compatibility (EMC) 22

Electronic temp. 70

Empty calibr. 51

Empty calibration ("Dry" operating mode) 52

Error codes 81

Error signal 80

Ex area 4

Extended calibr. 64

External cleaning 78

F

Fieldbus connector 24

Full calibr. 51

Full calibration ("Dry" operating mode) 52

Function and subfunction 35

Function switch 44

G

Green LED flashing 80

Ground tube 12

H

Handheld terminal DXR375 42

HART 26

HART - connecting with other supply units 26

HART address 66

HART handheld terminal DXR 375 42

HART settings 66

I

Inactive length 12

Incoming acceptance 8

Initial commissioning 48

Installation 8

Installation and function check 43

Intermed. height 62

K

Key combinations 30

Key locking 40

Key unlocking 40

Keys (softkey operation) 30

L

Language 69

Last error 69

Last errors 80

Launching menus 33

Linearization 48, 58, 61

Locking 40

M

Maintenance 78

Marine approval (GL) 10

Max. capacity 70

Max. scale	63
Max. temp.	70
Measure capacity	51, 70
Measured value display	39
Measuring condition	10
Measuring modes	44
Measuring range	21, 46, 64
Medium	44, 50
Medium property	44, 50
Menu-guided commissioning	41
Min. capacity	70
Min. temp.	70
Min/Max capacity	70
Min/Max temp.	70
Mode	61

N

Nameplate	6
Navigating in the menu	32
Next highest	40
No. of decimals	69
No. of preambles	66
Notes on safety conventions and icons	5

O

Operating menu	31
Operating menu (overview)	95
Operating mode	55–56
Operating options	27
Operation	72
Operational safety	4
Orientation	9
Output	48, 64
Output 1	55
Output damping	53, 55–56
Output on alarm	57
Output value	57
Output/Calculat	66
Output/calculat	65

P

Parameter okay	55–56
Password/reset	70
Performance characteristics	86
Pipe mounting	18
Planning instructions	9
Post-connection check	26
Post-installation check	21
Potential equalization	22
Probe length	71
Proof test	46, 57
Protective cover	79

R

Red LED flashing	80
Repair	78
Repairing Ex-certified devices	78
Replacement	78
Reset	40, 46, 70
Restore factory settings	46

Return	83
Rod probes	11
Rope probes	14
Rotating the housing	20

S

Safety instructions	4–5
Safety setting	48, 54
Safety settings	54
Sealing (housing)	21
Seals	78
Self-test	46
Sensor DAT	65
Sensor DAT stat.	65
Sep. character	69
Separate housing	16
Separate housing (shortening the connecting cable) ...	18
Serial No.	71
Short TAG HART	66
Shortening set	79
Shortening the rope	15
SIL operating mode	56
Sim. level value	61
Sim. vol. value	61
Simulation	61, 67
Simulation value	67
Software history	84
Software locking	40
Software version	71
Spare Parts	83
Status	55–56
Status table	63
Storage	8
Storage temperature	8
Submenus	34
System parameters	71

T

Table editor	62
Technical data	85
Temperature unit	70
Tensioning weight with tension	15
ToF Tool	26, 41
ToF Tool - FieldTool Package	41
Troubleshooting	80
Troubleshooting instructions	80
Turn down 20 mA	65
Turn down 4 mA	65
Type	59
Type of protection	5
Types of error	81

U

Unit level	51
------------------	----

V

Value empty	51–52, 55
Value full	51, 55

W	
Wall bracket	17
Wall mounting	17
Wet calibration	
.....	48
Wiring	22
Working hour	71



www.addresses.endress.com
